
ON-BOARD DIAGNOSTIC SYSTEM ACTIVE COMMAND MODES FUNCTION

id030200108500

- The active command modes function is used for optionally selecting simulation items of input/output parts preset in the 4WD CM, and to operate them regardless of CM control.

ACTIVE COMMAND MODE TABLE

Command name	Output part name	Operation	Operating condition
CUP_SOL	Coupling component	Off/On	Switch the ignition to ON (engine off or on)