

# DTC U201F:11 [START STOP UNIT]

id0902p6024300

<b>System malfunction location</b>	<b>Keyless receiver circuit malfunction</b>
<b>Detection condition</b>	• Start stop unit detects keyless receiver circuit voltage of <b>less than 3.4 V</b> for <b>0.5 s or more</b> .
<b>Fail-safe</b>	—
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>• Keyless receiver connector or terminal malfunction</li> <li>• Start stop unit connector or terminal malfunction</li> <li>• Short to ground in wiring harness between start stop unit terminal 2Q and keyless receiver terminal A</li> <li>• Keyless receiver malfunction</li> <li>• Start stop unit malfunction</li> </ul>
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>START STOP UNIT</p> <p>START STOP UNIT WIRING HARNESS-SIDE CONNECTOR</p> </div> <div style="text-align: center;"> <p>KEYLESS RECEIVER</p> <p>KEYLESS RECEIVER WIRING HARNESS-SIDE CONNECTOR</p> </div> </div> <p>Wiring diagram showing connections: 2Q to A, 2R to B, and D to ground.</p>	

## Diagnostic Procedure

Step	Inspection	Action
1	<b>INSPECT KEYLESS RECEIVER CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Disconnect the keyless receiver connector</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	<div>Yes</div> Go to the next step.
		<div>No</div> Repair or replace the connector, then go to Step 5.
2	<b>INSPECT START STOP UNIT CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the start stop unit connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	<div>Yes</div> Go to the next step.
		<div>No</div> Repair or replace the connector, then go to Step 5.

Step	Inspection	Action
3	<b>INSPECT KEYLESS RECEIVER CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the keyless receiver and start stop unit connectors are disconnected.</li> <li>• Inspect for continuity between keyless receiver terminal A (vehicle wiring harness side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes Repair or replace the wiring harness which is shorted to ground, then go to Step 5.
		No Go to the next step.
4	<b>INSPECT KEYLESS RECEIVER</b> <ul style="list-style-type: none"> <li>• Inspect the keyless receiver. (See KEYLESS RECEIVER INSPECTION.)</li> <li>• Is the keyless receiver normal?</li> </ul>	Yes Go to the next step.
		No Replace the keyless receiver, then go to the next step. (See KEYLESS RECEIVER REMOVAL/INSTALLATION.)
5	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>• Reconnect all the disconnected connectors.</li> <li>• Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].)</li> <li>• Switch the ignition ON (engine off or on) and wait for <b>0.5 s or more</b>.</li> <li>• Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].)</li> <li>• Is DTC U201F:11 displayed?</li> </ul>	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
6	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>• Are any other DTCs displayed?</li> </ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.