

---

## AIR CLEANER ELEMENT INSPECTION [SKYACTIV-D 2.2]

id0113z7800800

1. Remove the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
2. Inspect the following items:
  - Has the replacement date expired?
  - Is there dirt, damage, or deformity on the air cleaner element?
  - Is the sealing for the air cleaner case and air cleaner element in good condition?
  - Is the correct air cleaner element installed?
    - If there is any malfunction, clean or replace the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)