

## CRANKSHAFT POSITION (CKP) SENSOR [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0140g2006300

### Purpose/Function

- Detects the crankshaft speed as basic information for mainly determining the fuel injection timing and ignition timing.
- Detects the crankshaft speed and sends it to the PCM as a CKP signal.

### Construction


- Installed on the side of the cylinder block (right side).
- An MR (Magnetic Resistance) element has been adopted as the detecting element for detecting the crankshaft speed.



ac5wzn00002585


### Operation

- Sends the signal, which fluctuates according to the crankshaft speed, to the PCM.



ac5wzn00002586

**CKP sensor characteristic**



**Fail-safe**

DTC No.	Fail-safe function
P0335:00	<ul style="list-style-type: none"><li>• Stops fuel injection</li><li>• Stops ignition</li></ul>