

DTC U3000:66 [LASER SENSOR]

id0402c4895400

DTC	U3000:66	Laser sensor malfunction
DETECTION CONDITION	• Laser sensor detects a large number of consecutive drive cycles with the smart city brake support (SCBS) system malfunction.	
FAIL-SAFE FUNCTION	• Inhibits the smart city brake support (SCBS) controls. • Illuminates the master warning light • The message "SCBS Inspection Required" is indicated in the display.	
POSSIBLE CAUSE	• Laser sensor malfunction • Instrument cluster malfunction	
SYSTEM WIRING DIAGRAM	—	

Diagnostic procedure

STEP	INSPECTION		ACTION
1	INSPECT FOR INSTRUMENT CLUSTER MALFUNCTION <ul style="list-style-type: none">• Switch the ignition to off.• Using the M-MDS, perform the DTC inspection for the DSC HU/CM. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)• Are any other DTCs detected?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
2	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none">• Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [LASER SENSOR].)
		No	Go to the next step.
3	VERIFY THAT THE SAME DTC IS NOT PRESENT <ul style="list-style-type: none">• Clear the DTCs from the memory. (See ON-BOARD DIAGNOSIS [LASER SENSOR].)• Are the same DTCs present?	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the laser sensor. (See LASER SENSOR REMOVAL/INSTALLATION.)
		No	DTC troubleshooting completed.