

<b>DTC P2507:00</b>	<b>PCM battery voltage low input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>The PCM monitors the voltage of backup battery positive terminal. If the PCM detects that the battery positive terminal voltage is <b>below 6 V for 5 s</b>, the PCM determines that the backup voltage circuit has a malfunction.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>Battery voltage: <b>8 V or more</b></li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Inhibits engine-stop by operating the i-stop function.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Battery malfunction</li> <li>Short to ground or open circuit in backup voltage circuit <ul style="list-style-type: none"> <li>Short to ground in wiring harness between MAIN 200 A fuse and PCM terminal 2O</li> <li>MAIN 200 A fuse and/or ENG.+B 7.5 A fuse malfunction</li> <li>Open circuit in wiring harness between battery positive terminal and PCM terminal 2O</li> </ul> </li> <li>PCM connector or terminals malfunction</li> <li>PCM malfunction</li> </ul>

## Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	<b>INSPECT BATTERY</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes Recharge or replace the battery, then go to Step 6. (See BATTERY RECHARGING [SKYACTIV-D 2.2].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No Go to the next step.

STEP	INSPECTION	ACTION	
4	<b>INSPECT BACKUP VOLTAGE CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Reconnect all disconnected connectors.</li> <li>• Access the VPWR PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Verify the VPWR PID value.</li> <li>• Is the VPWR PID value <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and ENG.+B 7.5 A fuse. <ul style="list-style-type: none"> <li>• If the fuse is blown:               <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness for a possible short to ground.</li> <li>— Replace the malfunctioning fuse.</li> </ul> </li> <li>• If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>— Replace the malfunctioning fuse.</li> </ul> </li> <li>• If all fuses are normal:               <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness for a possible open circuit.</li> </ul> </li> </ul> Go to Step 6.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	Go to the next step.
6	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to the next step.
		No	Go to the next step.
7	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.