

# DTC P0113:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4701500

<b>DTC P0113:00</b>	<b>IAT sensor No.1 circuit high input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>The PCM monitors the IAT sensor No.1 signal. If the PCM detects that the IAT sensor No.1 voltage at the PCM terminal 2U is <b>above 4.62 V</b> for <b>5 s</b>, the PCM determines that the IAT sensor No.1 circuit has a malfunction.</li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Fixes intake air temperature (for engine control) at <b>20 °C {68 °F}</b></li> <li>Inhibits the fuel cut control during shift change.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>MAF sensor/IAT sensor No.1 connector or terminals malfunction</li> <li>PCM connector or terminals malfunction</li> <li>IAT sensor No.1 malfunction</li> <li>Short to power supply in wiring harness between MAF sensor/IAT sensor No.1 terminal A and PCM terminal 2U</li> <li>Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>MAF sensor/IAT sensor No.1 terminal A—PCM terminal 2U</li> <li>MAF sensor/IAT sensor No.1 terminal B—PCM terminal 2AY</li> </ul> </li> <li>PCM malfunction</li> </ul>
<div> <div> <p>⑥⑨</p> <p>IAT SENSOR NO.1 (MAF SENSOR/IAT SENSOR NO.1)</p> </div> <div> <p>PCM</p> </div> <div> <p>MAF SENSOR/IAT SENSOR NO.1 WIRING HARNESS-SIDE CONNECTOR</p> </div> <div> <p>PCM WIRING HARNESS-SIDE CONNECTOR</p> </div> </div>	

## Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
3	<b>DETERMINE IF IAT SENSOR NO.1 OR WIRING HARNESS MALFUNCTION</b> <ul style="list-style-type: none"> <li>Access the IAT PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Verify the IAT PID value.</li> <li>Is the IAT PID value <b>5 V</b> or <b>B+</b>?</li> </ul>	Yes	Go to Step 7.
		No	Go to the next step.
4	<b>INSPECT MAF SENSOR/IAT SENSOR NO.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the MAF sensor/IAT sensor No.1 connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	<b>INSPECT IAT SENSOR NO.1</b> <ul style="list-style-type: none"> <li>Inspect the IAT sensor No.1. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the MAF sensor/IAT sensor No.1, then go to Step 10. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to Step 10.
7	<b>DETERMINE IF IAT SENSOR NO.1 SIGNAL CIRCUIT OR IAT SENSOR NO.1 GROUND CIRCUIT MALFUNCTION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the MAF sensor/IAT sensor No.1 connector.</li> <li>Access the IAT PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Verify the IAT PID value.</li> <li>Is the IAT PID value <b>5 V</b> or <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 9.
8	<b>INSPECT IAT SENSOR NO.1 SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>Switch the ignition off.</li> <li>Disconnect the PCM connector.</li> <li>Inspect for continuity between MAF sensor/IAT sensor No.1 terminal A (wiring harness-side) and PCM terminal 2U (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 10.
9	<b>INSPECT IAT SENSOR NO.1 GROUND CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>Switch the ignition off.</li> <li>Disconnect the PCM connector.</li> <li>Inspect for continuity between MAF sensor/IAT sensor No.1 terminal B (wiring harness-side) and PCM terminal 2AY (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Replace the MAF sensor/IAT sensor No.1, then go to the next step. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.

STEP	INSPECTION		ACTION
10	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Start the engine and warm it up completely.</li> <li>• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to the next step.
		No	Go to the next step.
11	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.