

NO.26 EXHAUST SULPHUR SMELL [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0103g3803200

26	EXHAUST SULPHUR SMELL
DESCRIPTION	<ul style="list-style-type: none"> • Rotten egg smell (sulphur) from exhaust.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Electrical connectors are disconnected or connected poorly • Vacuum lines are disconnected or connected improperly. • Poor fuel quality • PCM DTC is stored • Inadequate fuel pressure <ul style="list-style-type: none"> — Fuel pressure sensor malfunction — High pressure fuel pump malfunction — Spill valve control solenoid valve control circuit malfunction (damage to driver in PCM caused by short circuit to ground system) — Spill valve control solenoid valve (built-into high pressure fuel pump) malfunction — Relief valve (built-into high pressure fuel pump) malfunction — Fuel line restricted — Fuel pump unit malfunction • Charcoal canister malfunction • Fuel tank vent system malfunction <p>Warning The following troubleshooting flow chart contains the fuel system diagnosis and repair procedures. Read the following warnings before performing the fuel system services:</p> <ul style="list-style-type: none"> • Fuel vapor is hazardous. It can easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel. • Fuel line spills and leakage are dangerous. Fuel can ignite and cause serious injury or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete “BEFORE SERVICE PRECAUTION” and “AFTER SERVICE PRECAUTION” described in this manual. (See BEFORE SERVICE PRECAUTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See AFTER SERVICE PRECAUTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) <p>Caution • Disconnecting/connecting the quick release connector without cleaning it may possibly cause damage to the fuel pipe and quick release connector. Always clean the quick release connector joint area before disconnecting/connecting, and make sure that it is free of foreign matter.</p>

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	VERIFY IF THERE IS POOR DRIVEABILITY OR EXHAUST GAS RELATED MALFUNCTION <ul style="list-style-type: none"> • Are any driveability or exhaust smoke concerns present? 	Yes	Go to the applicable symptom troubleshooting. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
2	INSPECT RELATED PART CONDITION <ul style="list-style-type: none"> • Inspect the following: <ul style="list-style-type: none"> — Electrical connections — Vacuum lines — Fuel quality • Is there any malfunction? 	Yes	Service if necessary. • Repeat this step.
		No	Go to the next step.
3	VERIFY PCM DTC <ul style="list-style-type: none"> • Retrieve any DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
4	INSPECT FUEL PRESSURE (HIGH-SIDE) <ul style="list-style-type: none"> Start the engine and warm it up completely. Access the FUEL_PRES PID using the M-MDS at idle. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the FUEL_PRES PID value approx. 3 MPa {31 kgf/cm², 435 psi}? 	Yes	Go to Step 8.
		No	Lower than 3 MPa {31 kgf/cm², 435 psi} : <ul style="list-style-type: none"> Inspect the following: <ul style="list-style-type: none"> Fuel leakage at the fuel line and fuel injector Fuel pump <ul style="list-style-type: none"> Perform the Fuel Pump (Low-pressure Side) Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Fuel pressure sensor (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) High pressure fuel pump (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Go to Step 7. Higher than 3 MPa {31 kgf/cm², 435 psi} : <ul style="list-style-type: none"> Go to the next step.
5	DETERMINE IF MALFUNCTION CAUSE IS FUEL PRESSURE SENSOR OR HIGH PRESSURE FUEL PUMP <ul style="list-style-type: none"> Is the vehicle acceleration performance normal? 	Yes	Go to the next step.
		No	Go to Step 7.
6	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the fuel distributor. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to Step 8.
7	INSPECT SPILL VALVE CONTROL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Switch the ignition off. Disconnect the high pressure fuel pump and PCM connectors. Inspect for continuity between high pressure fuel pump terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground. <ul style="list-style-type: none"> If the malfunction remains: <ul style="list-style-type: none"> Replace the PCM. (damage to driver in PCM) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Replace the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
8	INSPECT FUEL PRESSURE (LOW-SIDE) <ul style="list-style-type: none"> Connect the fuel pressure gauge between fuel pump and high pressure fuel pump. Measure the low side fuel pressure. (See FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the low side fuel pressure within specification? Specification: <ul style="list-style-type: none"> 405—485 kPa {4.13—4.94 kgf/cm², 58.8—70.3 psi} 	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> Fuel line restriction Fuel filter clogged <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Replace the fuel pump unit. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)

STEP	INSPECTION	RESULTS	ACTION
9	DETERMINE IF MALFUNCTION CAUSE IS CHARCOAL CANISTER OR FUEL TANK VENT SYSTEM <ul style="list-style-type: none"> Inspect the charcoal canister for fuel saturation. (See CHARCOAL CANISTER INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there excess amount of liquid fuel present in canister? 	Yes	Replace the charcoal canister. (See CHARCOAL CANISTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Inspect the fuel tank vent system. <ul style="list-style-type: none"> If the fuel tank vent system is normal: <ul style="list-style-type: none"> Suggest trying a different brand since sulfur content can vary in different fuels. If fuel tank vent system is not normal: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results.
10	Verify the test results. <ul style="list-style-type: none"> If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. <ul style="list-style-type: none"> If the vehicle is repaired, troubleshooting is completed. If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) 		