


DTC U3006:62 [FRONT BODY CONTROL MODULE (FBCM)]

id0902p2011800

System malfunction location	Front body control module (FBCM) power supply voltage mismatch
Detection condition	<ul style="list-style-type: none"> • Front body control module (FBCM) terminal 1A, 1B, 3K, and 3L voltages of 2 V or more lower than the voltage of terminal 2A are detected for 5 s or more with the ignition switched ON (engine off or on).
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> • Front body control module (FBCM) connector or terminal malfunction • Front body control module (FBCM) power supply circuit malfunction <ul style="list-style-type: none"> — Short to ground in the wiring harness between ROOM 15 A fuse and front body control module (FBCM) terminal 2A — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 1A — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 1B — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 3K — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 3L — ROOM 15 A fuse malfunction — HAZARD 25 A fuse malfunction — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 2A — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 1A — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 1B — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 3K — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 3L • Front body control module (FBCM) malfunction



Diagnostic Procedure

Step	Inspection	Action
1	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN <ul style="list-style-type: none"> Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) Switch the ignition ON (engine off or on) and wait for 5 s or more. Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Is DTC U3006:62 displayed? 	Yes Go to the next step. No Go to Step 6.
2	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs <ul style="list-style-type: none"> Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Is the DTC displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].) No Go to the next step.

Step	Inspection	Action	
3	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Disconnect the front body control module (FBCM) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
4	VERIFY FRONT BODY CONTROL MODULE (FBCM) POWER SUPPLY VOLTAGE <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Display PID VPWR_B using the M-MDS. (See PID/DATA MONITOR INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ROOM 15 A and HAZARD 25 A fuses. <ul style="list-style-type: none"> • If a fuse is burnt out: <ul style="list-style-type: none"> — Repair or replace the wiring harness which is shorted to ground. — Replace the burnt out fuse. • If a fuse is damaged: <ul style="list-style-type: none"> — Replace the damaged fuse. • All fuses are normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness which has an open circuit. Go to the next step.

Step	Inspection	Action
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Switch the ignition ON (engine off or on) and wait for 5 s or more. • Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is DTC U3006:62 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
6	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.