


DTC P0337:00 [SKYACTIV-D 2.2]

id0102s4154800

DTC P0337:00	CKP sensor circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> • There is no CKP sensor signal input while the crankshaft rotates 12 times. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • PCM restricts engine torque. • Inhibits the EGR control. • Inhibits the diesel particulate filter regeneration control. • Inhibits engine-stop by operating the i-stop function. • PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • CKP sensor connector or terminals malfunction • Improper installation of CKP sensor • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — CKP sensor terminal A—PCM terminal 1J — CKP sensor terminal C—PCM terminal 1E • PCM connector or terminals malfunction • Short to power supply in wiring harness between CKP sensor terminal C and PCM terminal 1E • CKP sensor circuits are shorted to each other • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — CKP sensor terminal A—PCM terminal 1J — CKP sensor terminal C—PCM terminal 1E — CKP sensor terminal B—PCM terminal 1F • CKP sensor pulse wheel malfunction • CKP sensor detection area is dirty • CKP sensor malfunction • PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT CKP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the CKP sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
4	INSPECT CKP SENSOR INSTALLATION CONDITION <ul style="list-style-type: none"> Inspect for CKP sensor looseness. Is the CKP sensor loosen? 	Yes	Install the CKP sensor properly, then go to Step 11. (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
5	INSPECT CKP SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the CKP sensor connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — CKP sensor terminal A — CKP sensor terminal C • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 11.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
7	INSPECT CKP SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the CKP sensor and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the CKP sensor terminal C (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 11.
8	INSPECT CKP SENSOR CIRCUITS FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the CKP sensor and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between CKP sensor terminals A, C and B (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 11.
		No	Go to the next step.
9	INSPECT CKP SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the CKP sensor and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — CKP sensor terminal A—PCM terminal 1J — CKP sensor terminal C—PCM terminal 1E — CKP sensor terminal B—PCM terminal 1F • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 11.
10	INSPECT CKP SENSOR <ul style="list-style-type: none"> • Inspect the CKP sensor. (See CRANKSHAFT POSITION (CKP) SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the CKP sensor, then go to the next step. (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Damage to the CKP sensor pulse wheel can be considered the cause. <ul style="list-style-type: none"> • Overhaul the engine, inspect the CKP sensor pulse wheel. <ul style="list-style-type: none"> — If there is any malfunction: <ul style="list-style-type: none"> • Replace the CKP sensor pulse wheel, then go to the next step. — If there is no malfunction: <ul style="list-style-type: none"> • Go to the next step.

STEP	INSPECTION	ACTION
11	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Start the engine. • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No Go to the next step.
12	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No DTC troubleshooting completed.