
DTC INSPECTION [ADVANCED KEYLESS ENTRY SYSTEM]

id0902p8025800

CMDTC Self Test

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
 - (1) Select "Self Test".
 - (2) Select "All CMDTCs".
3. Verify the DTC according to the directions on the screen.
 - If any DTCs are displayed, perform troubleshooting according to the corresponding DTC inspection.
4. After completion of repairs, clear all DTCs stored in the start stop unit. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].)

ODDTC Self Test

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
 - (1) Select "Self Test".
 - (2) Select "Modules".
 - (3) Select "SSU".
3. Verify the DTC according to the directions on the screen.
 - If any DTCs are displayed, perform troubleshooting according to the corresponding DTC inspection.
4. After completion of repairs, clear all DTCs stored in the start stop unit. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].)