

## NO.7 NO COOL AIR [MANUAL AIR CONDITIONER]

id0702c2812600

7	No cool air
DESCRIPTION	<ul style="list-style-type: none"> <li>• Magnetic clutch does not operate</li> </ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>• Malfunction in PCM A/C cut control system</li> <li>• Open or short circuit in wiring harness between evaporator temperature sensor and climate control unit</li> <li>• Malfunction in evaporator temperature sensor (internal circuit malfunction)</li> <li>• Malfunction in climate control unit</li> <li>• Malfunction in refrigerant pressure sensor</li> <li>• Malfunction in PCM (A/C signal)</li> <li>• Malfunction in PCM (IG1 signal)</li> <li>• Malfunction in A/C compressor</li> <li>• Malfunction in A/C relay</li> <li>• Malfunction in evaporator temperature sensor</li> <li>• Malfunction in front body control module (FBCM)</li> <li>• Improper refrigerant charging amount</li> <li>• Open circuit in wiring harness between front body control module (FBCM) and climate control unit</li> <li>• Malfunction in CAN communication</li> </ul>

- When performing an asterisked (\*) troubleshooting inspection, shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.

### Diagnostic procedure

STEP	INSPECTION		ACTION
1	<b>CHECK MALFUNCTION SYMPTOMS</b>  <b>Note</b> <ul style="list-style-type: none"> <li>• Without i-stop, go to the next step.</li> </ul> <ul style="list-style-type: none"> <li>• Is malfunctions occur in only when operating the i-stop?</li> </ul>	Yes	Perform the i-stop troubleshooting. (See FOREWORD [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See FOREWORD [SKYACTIV-D 2.2].)
		No	Go to the next step.
2	<b>INSPECT FUSE</b> <ul style="list-style-type: none"> <li>• Are A/C relay power supply fuses okay?</li> </ul>	Yes	Go to the next step.
		No	Replace fuse, then go to Step 16. If fuse burns out immediately, go to the next step.
3	<b>INSPECT AIR BLOW OUT</b> <ul style="list-style-type: none"> <li>• Does air blow out?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 1 of troubleshooting indexes No.1 and 2.
4	<b>INSPECT A/C COMPRESSOR OPERATION</b> <ul style="list-style-type: none"> <li>• Start engine.</li> <li>• Turn A/C switch and fan switch on.</li> <li>• Does A/C compressor operate?</li> </ul>	Yes	Go to Step 1 of troubleshooting index No.6.
		No	Go to the next step.
5	<b>INSPECT FOR DTC IN PCM AND FRONT BODY CONTROL MODULE (FBCM)</b> <ul style="list-style-type: none"> <li>• Inspect for DTCs related to the PCM and front body control module (FBCM) on-board diagnostic system.</li> <li>• Are any DTCs displayed?</li> </ul>	Yes	Go to appropriate inspection procedure.
		No	Go to the next step.
6	<b>DETERMINE IF MALFUNCTION CAUSE IS A/C REQUEST SIGNAL OR A/C RELAY OPERATIONAL MALFUNCTION</b> <ul style="list-style-type: none"> <li>• Access PCM PID ACCS using the M-MDS.</li> <li>• Start the engine and idle it.</li> <li>• Turn the PID ACCS to ON from OFF using the M-MDS simulation function.</li> <li>• Is the A/C magnetic clutch engaged?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 11.
7*	<b>SIGNAL INSPECTION FROM EVAPORATOR TEMPERATURE SENSOR TO CLIMATE CONTROL UNIT</b> <ul style="list-style-type: none"> <li>• Remove the climate control unit.</li> <li>• Reconnect the climate control unit connector.</li> <li>• Measure the climate control unit terminal H voltage. (See CLIMATE CONTROL UNIT INSPECTION [MANUAL AIR CONDITIONER].)</li> <li>• Is the voltage within the specified?</li> </ul>	Yes	Go to Step 9.
		No	Go to the next step.

STEP	INSPECTION		ACTION
8	<b>INSPECT EVAPORATOR TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the evaporator temperature sensor. (See EVAPORATOR TEMPERATURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].)</li> <li>Is the evaporator temperature sensor normal?</li> </ul>	Yes	Inspect and repair for open or short circuit between evaporator temperature sensor and climate control unit.
		No	Replace the evaporator temperature sensor. (See A/C UNIT DISASSEMBLY/ASSEMBLY.)
9	<b>INSPECT REFRIGERANT PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect refrigerant pressure sensor. (See REFRIGERANT PRESSURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].)</li> <li>Is the refrigerant pressure sensor normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace malfunctioning part according to inspection result, then go to Step 17.
10	<b>CONTINUITY INSPECTION BETWEEN CLIMATE CONTROL UNIT AND INSTRUMENT CLUSTER</b> <ul style="list-style-type: none"> <li>Inspect for open or short circuit between climate control unit terminal K and front body control module (FBCM) terminal 2J.</li> <li>Is there any open or short circuit detected?</li> </ul>	Yes	Repair for open or short circuit.
		No	Replace the climate control unit. (A/C switch malfunction or climate control unit does not determine A/C request or transmit the A/C request signal.) (See CLIMATE CONTROL UNIT REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER].)
11	<b>INSPECT TO SEE WHETHER MALFUNCTION (LACK OF CONTINUITY) IS IN A/C CONTROL SIGNAL CIRCUIT (BETWEEN A/C RELAY AND PCM) OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>Does cool air blow out when terminal E of A/C relay connector (A/C control signal) is grounded?</li> </ul>	Yes	Release short, then go to the next step.
		No	Go to Step 13.
12*	<b>INSPECT TO SEE WHETHER MALFUNCTION (LACK OF CONTINUITY) IS IN PCM OR WIRING HARNESS (BETWEEN A/C RELAY AND PCM)</b> <ul style="list-style-type: none"> <li>Test voltage at the A/C relay control signal terminal of PCM.</li> <li>Is voltage <b>approx. 12 V</b>?</li> </ul>	Yes	Inspect PCM, then go to Step 17.
		No	Repair wiring harness between A/C relay and PCM, then go to Step 17.
13*	<b>INSPECT TO SEE WHETHER MALFUNCTION IS IN MAGNETIC CLUTCH OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>Test voltage at the following terminal of magnetic clutch. <ul style="list-style-type: none"> <li>Terminal A (magnetic clutch operation signal)</li> </ul> </li> <li>Is voltage <b>approx. 12 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 15.
14	<b>INSPECT MAGNETIC CLUTCH CLEARANCE</b> <ul style="list-style-type: none"> <li>Inspect the magnetic clutch clearance. (See MAGNETIC CLUTCH ADJUSTMENT [MANUAL AIR CONDITIONER].)</li> <li>Is the magnetic clutch clearance normal?</li> </ul>	Yes	Inspect and repair the magnetic clutch, then go to Step 17. (See MAGNETIC CLUTCH INSPECTION [MANUAL AIR CONDITIONER].)
		No	Adjust the magnetic clutch clearance, then go to Step 17. (See MAGNETIC CLUTCH ADJUSTMENT [MANUAL AIR CONDITIONER].)
15	<b>INSPECT WIRING HARNESS BETWEEN FUSE BLOCK AND A/C RELAY FOR LACK OF CONTINUITY</b> <ul style="list-style-type: none"> <li>Test voltages at following terminals of A/C relay. <ul style="list-style-type: none"> <li>Terminal A (A/C relay control signal)</li> <li>Terminal C (A/C control signal)</li> </ul> </li> <li>Are voltages <b>approx. 12 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Repair wiring harness between fuse block and A/C relay, then go to Step 17.
16	<b>INSPECT TO SEE WHETHER MALFUNCTION IS IN A/C RELAY OR WIRING HARNESS (BETWEEN A/C RELAY AND MAGNETIC CLUTCH)</b> <ul style="list-style-type: none"> <li>Test voltage at the following terminal of A/C relay. <ul style="list-style-type: none"> <li>Terminal D (magnetic clutch operation signal)</li> </ul> </li> <li>Is voltage <b>approx. 12 V</b>?</li> </ul>	Yes	Inspect wiring harness between A/C relay and magnetic clutch. <ul style="list-style-type: none"> <li>If above wiring harness is OK, go to the next step.</li> <li>If above wiring harness malfunctions, repair wiring harness, then go to the next step.</li> </ul>
		No	Replace A/C relay, then go to the next step.

---

STEP	INSPECTION		ACTION
17	<b>CONFIRM THAT MALFUNCTION SYMPTOMS DO NOT RECUR AFTER REPAIR</b> • Does cool air blow out? (Are the results of refrigerant system performance test okay?)	Yes	Troubleshooting completed. Explain repairs to customer.
		No	Recheck malfunction symptoms, then repeat from Step 1 if malfunction recurs.