

Caution

- Vehicle specifications differ depending on the vehicle identification number (VIN).

- **Type A VIN:**

- JM0 KE***** 100001—

- JM6 KE***** 100001—

- JM7 KE***** 100001—

- JM8 KE***** 100001—

- JMZ KE***** 100001—

- KE10** 100001—

- **Type B VIN:**

- JM0 KE***** 200001—


- JM6 KE***** 200001—

- JM8 KE***** 200001—

- JMZ KE***** 200001—

- KE10** 200001—

DTC P0443:00	Purge solenoid valve circuit problem
DETECTION CONDITION	<p>Type A VIN</p> <ul style="list-style-type: none"> • The PCM monitors the purge solenoid valve control signal voltage and current. If the following conditions are met, the PCM determines that there is the purge solenoid valve control circuit problem. <ul style="list-style-type: none"> — The PCM turns the purge solenoid valve off, but the voltage of the purge solenoid valve control signal remains low. — The PCM turns the purge solenoid valve on, but the current of the purge solenoid valve control signal remains high. <p>Type B VIN</p> <ul style="list-style-type: none"> • The purge control voltage at the PCM terminal 1AI exceeds the specification or the purge control voltage is less than the specification relative to the PCM control condition. <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM. • PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Purge solenoid valve connector or terminals malfunction • Short to ground or open circuit in purge solenoid valve power supply circuit <ul style="list-style-type: none"> — Short to ground in wiring harness between ENGINE2 15 A fuse and purge solenoid valve terminal B — ENGINE2 15 A fuse malfunction — Open circuit in wiring harness between main relay terminal C and purge solenoid valve terminal B • PCM connector or terminals malfunction • Short to ground in wiring harness between purge solenoid valve terminal A and PCM terminal 1AI • Short to power supply in wiring harness between purge solenoid valve terminal A and PCM terminal 1AI • Open circuit in wiring harness between purge solenoid valve terminal A and PCM terminal 1AI • Purge solenoid valve malfunction • PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	INSPECT PURGE SOLENOID VALVE CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the purge solenoid valve connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	INSPECT PURGE SOLENOID VALVE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the purge solenoid valve connector is disconnected. Switch the ignition ON (engine off). Measure the voltage at the purge solenoid valve terminal B (wiring harness-side). Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE2 15 A fuse. <ul style="list-style-type: none"> If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the fuse. If the fuse is normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit. Go to Step 10.

STEP	INSPECTION	ACTION	
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	INSPECT PURGE SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the purge solenoid valve and PCM connectors are disconnected. Inspect for continuity between purge solenoid valve terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 10.
		No	Go to the next step.
7	INSPECT PURGE SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the purge solenoid valve and PCM connectors are disconnected. Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> Another DTC may be stored by the PCM detecting an open circuit. Measure the voltage at the purge solenoid valve terminal A (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.
8	INSPECT PURGE SOLENOID VALVE CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the purge solenoid valve and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between purge solenoid valve terminal A (wiring harness-side) and PCM terminal 1A1 (wiring harness-side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 10.
9	INSPECT PURGE SOLENOID VALVE <ul style="list-style-type: none"> Inspect the purge solenoid valve. (See PURGE SOLENOID VALVE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the purge solenoid valve, then go to the next step. (See PURGE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
10	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Start the engine. Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.