

DTC P0091:00	Fuel pressure regulator control circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> When the PCM turns the spill valve control solenoid valve off but the spill valve control solenoid valve control circuit voltage is low for 5 s, the PCM determines that the spill valve control solenoid valve control circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> The following conditions are met: <ul style="list-style-type: none"> Engine speed: 5,700 rpm or less Battery voltage: 10.5 V or more <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Stops high pressure fuel pump control Limits intake air amount
POSSIBLE CAUSE	<ul style="list-style-type: none"> High pressure fuel pump connector or terminals malfunction PCM connector or terminals malfunction Short to ground in wiring harness between high pressure fuel pump terminal B and PCM terminal 1EF Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> High pressure fuel pump terminal A—PCM terminal 1EE High pressure fuel pump terminal B—PCM terminal 1EF Spill valve control solenoid valve (built-into high pressure fuel pump) malfunction PCM malfunction

⑦

SPILL VALVE CONTROL SOLENOID VALVE
(HIGH PRESSURE FUEL PUMP)

HIGH PRESSURE FUEL PUMP
WIRING HARNESS-SIDE
CONNECTOR

PCM

PCM WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT HIGH PRESSURE FUEL PUMP CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the high pressure fuel pump connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
5	INSPECT SPILL VALVE CONTROL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the high pressure fuel pump and PCM connectors are disconnected. Inspect for continuity between high pressure fuel pump terminal B (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 8.
		No	Go to the next step.
6	INSPECT SPILL VALVE CONTROL SOLENOID VALVE CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the high pressure fuel pump and PCM connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> High pressure fuel pump terminal A—PCM terminal 1EE High pressure fuel pump terminal B—PCM terminal 1EF Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
7	INSPECT SPILL VALVE CONTROL SOLENOID VALVE <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the spill valve control solenoid valve. (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the high pressure fuel pump, then go to the next step. (See HIGH PRESSURE FUEL PUMP REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Start the engine. Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.