







DTC B11F2:23 [REAR VEHICLE MONITORING SYSTEM]

id0902z2885300

System malfunction location	RVM switch circuit malfunction
Detection condition	<ul style="list-style-type: none"> The rear vehicle monitoring control module (RH) receives RVM switch ON signal from the instrument cluster for 2 min or more.
Fail-safe	<ul style="list-style-type: none"> Inhibits the rear vehicle monitoring system.
Possible cause	<ul style="list-style-type: none"> DTCs are stored in the instrument cluster. Cluster switch connector or terminal malfunction RVM switch malfunction Instrument cluster connector or terminal malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> Instrument cluster terminal V and cluster switch terminal B Instrument cluster terminal T and cluster switch terminal C Instrument cluster malfunction Rear vehicle monitoring control module (RH) malfunction
<div> <div> <div>INSTRUMENT CLUSTER</div>  </div> <div> <div>INSTRUMENT CLUSTER WIRING HARNESS-SIDE CONNECTOR</div>   </div> </div> <div> <div> <div>RVM SWITCH (CLUSTER SWITCH)</div>  </div> <div> <div>CLUSTER SWITCH WIRING HARNESS-SIDE CONNECTOR</div>   </div> </div>	

Diagnostic Procedure

Step	Inspection	Action
1	VERIFY INSTRUMENT CLUSTER DTCs <ul style="list-style-type: none"> Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) Is the DTC displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
	No	Go to the next step.

Step	Inspection	Action	
2	INSPECT CLUSTER SWITCH CONNECTOR <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Disconnect the cluster switch connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
3	INSPECT RVM SWITCH <ul style="list-style-type: none"> • Inspect the RVM switch. (See RVM SWITCH INSPECTION.) • Is the RVM switch normal? 	Yes	Go to the next step.
		No	Replace the cluster switch, then go to Step 7. (See SWITCH PANEL REMOVAL/INSTALLATION.)
4	INSPECT INSTRUMENT CLUSTER CONNECTOR <ul style="list-style-type: none"> • Disconnect the instrument cluster connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
5	INSPECT RVM SWITCH CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the cluster switch connector and instrument cluster connector are disconnected. • Inspect for continuity between the following terminals (vehicle wiring harness side) and body ground. <ul style="list-style-type: none"> — Cluster switch terminal B — Cluster switch terminal C • Is there continuity? 	Yes	Repair or replace the wiring harness which is shorted to ground, then go to Step 7.
		No	Go to the next step.
6	INSPECT INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is the instrument cluster normal? 	Yes	Go to the next step.
		No	Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)

Step	Inspection	Action
7	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for 2 min or more. • Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].) • Is DTC B11F2:23 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear vehicle monitoring control module (RH), then go to the next step. (See REAR VEHICLE MONITORING CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR VEHICLE MONITORING SYSTEM].)
		No DTC troubleshooting completed.