


DTC U3004:16 [START STOP UNIT]

id0902p6025200

System malfunction location	ACC relay circuit malfunction
Detection condition	<ul style="list-style-type: none"> With the ignition switched to ACC or ON (engine off or on), the start stop unit detects ACC monitor voltage of less than 2.5 V for 1 s or more.
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> ACC relay malfunction ACC relay power supply circuit malfunction <ul style="list-style-type: none"> Short to ground in wiring harness between IG2 30 A fuse and ACC relay terminal C IG2 30 A fuse malfunction Open circuit in wiring harness between battery positive terminal and ACC relay terminal C Start stop unit connector or terminal malfunction Start stop unit power supply circuit (ACC) malfunction <ul style="list-style-type: none"> Short to ground in wiring harness between ACC relay terminal D and start stop unit terminal 1E MIRROR 7.5 A fuse malfunction Open circuit in wiring harness between ACC relay terminal D and start stop unit terminal 1E Start stop unit malfunction
 <p>BATTERY</p> <p>RELAY AND FUSE BLOCK</p> <p>ACC RELAY</p> <p>IG2 30 A</p> <p>FUSE BLOCK</p> <p>MIRROR 7.5 A</p> <p>START STOP UNIT</p> <p>ACC RELAY (RELAY AND FUSE BLOCK)</p> <p>START STOP UNIT WIRING HARNESS-SIDE CONNECTOR</p> <p>FRONT</p> <p>1AE 1AC 1AA 1Y 1W 1U 1S 1Q 1O 1M 1K 1I 1G 1E 1C 1A 1AF 1AD 1AB 1Z 1X 1V 1T 1R 1P 1N 1L 1J 1H 1F 1D 1B</p> <p>2W 2U 2S 2Q 2O 2M 2K 2I 2G 2E 2C 2A 2X 2V 2T 2R 2P 2N 2L 2J 2H 2F 2D 2B</p>	

Diagnostic Procedure

Step	Inspection	Action
1	INSPECT ACC RELAY FOR MALFUNCTION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Remove the ACC relay. (See RELAY LOCATION.) Inspect the ACC relay. (See RELAY INSPECTION.) Is the ACC relay normal? 	<p>Yes Go to the next step.</p> <p>No Replace the ACC relay, then go to Step 5. (See RELAY LOCATION.)</p>

Step	Inspection	Action	
2	INSPECT ACC RELAY POWER SUPPLY CIRCUIT FOR OPEN CIRCUIT OR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the ACC relay is removed. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Switch the ignition to ACC or ON (engine off or on). • Measure the voltage at ACC relay terminal C (vehicle wiring harness side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the IG2 30 A fuse. <ul style="list-style-type: none"> • If a fuse is burnt out: <ul style="list-style-type: none"> — Repair or replace the wiring harness which is shorted to ground. — Replace the fuse. • If a fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness which has an open circuit. Go to Step 5.
3	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
4	INSPECT START STOP UNIT POWER SUPPLY CIRCUIT (ACC) FOR OPEN CIRCUIT OR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the start stop unit connector is disconnected. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Switch the ignition to ACC or ON (engine off or on). • Measure the voltage at ACC relay terminal E (vehicle wiring harness side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the MIRROR 7.5 A fuse. <ul style="list-style-type: none"> • If a fuse is burnt out: <ul style="list-style-type: none"> — Repair or replace the wiring harness which is shorted to ground. — Replace the fuse. • If a fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness which has an open circuit. Go to the next step.

Step	Inspection	Action
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition to ACC or ON (engine off or on) and wait for 1 s or more. • Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the DTC U3004:16 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
6	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.