



ac5wzw00005112

- | | |
|---|--|
| 1 | <p>Generator</p> <p>(See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <p>(See GENERATOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <p>(See GENERATOR DISASSEMBLY/ASSEMBLY [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> |
|---|--|

- | | |
|---|--|
| 2 | <p>Battery</p> <p>(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <p>(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)</p> <p>(See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <p>(See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <p>(See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)</p> <p>(See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <p>(See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)</p> <p>(See BATTERY CONDITION INITIALIZATION SETTING (i-stop SETTING) [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> |
|---|--|

3	DC-DC converter (vehicle with i-stop) (See DC-DC CONVERTER REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DC-DC CONVERTER INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
---	---