

# DTC P0098:00 [SKYACTIV-D 2.2]

id0102s4146500

DTC P0098:00	IAT sensor No.2 circuit high input
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>The PCM monitors the input signal from the IAT sensor No.2. If the voltage from the IAT sensor No.2 is <b>above 4.90 V</b> for <b>1 s</b>, the PCM determines that the IAT sensor No.2 circuit has a malfunction.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>Battery voltage: <b>8—20 V</b></li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Inhibits the EGR control.</li> <li>Inhibits engine-stop by operating the i-stop function.</li> <li>PCM restricts engine-transaxle integration control.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Intake air temperature is too low</li> <li>IAT sensor No.2 connector or terminals malfunction</li> <li>IAT sensor No.2 malfunction</li> <li>PCM connector or terminals malfunction</li> <li>Short to power supply in wiring harness between IAT sensor No.2 terminal A and PCM terminal 2N</li> <li>Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>IAT sensor No.2 terminal A—PCM terminal 2N</li> <li>IAT sensor No.2 terminal B—PCM terminal 2AV</li> </ul> </li> <li>PCM malfunction</li> </ul>

## Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes Go to the next step. No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. No Go to the next step.

STEP	INSPECTION	ACTION	
3	<b>INSPECT IAT SENSOR NO.2 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the IAT sensor No.2 connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	<b>INSPECT IAT SENSOR NO.2</b> <ul style="list-style-type: none"> <li>Inspect the IAT sensor No.2. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the IAT sensor No.2, then go to Step 8. (See INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to Step 8.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	<b>INSPECT IAT SENSOR NO.2 CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>Verify that the IAT sensor No.2 and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off).</li> <li>Measure the voltage at the IAT sensor No.2 terminal A (wiring harness-side).</li> <li>Is the voltage <b>0 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
7	<b>INSPECT IAT SENSOR NO.2 CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the IAT sensor No.2 and PCM connectors are disconnected.</li> <li>Switch the ignition off.</li> <li>Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>IAT sensor No.2 terminal A—PCM terminal 2N</li> <li>IAT sensor No.2 terminal B—PCM terminal 2AV</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)</li> <li>Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.