
DTC: U3000:04, 09:Er22 [AUDIO]

id0902f6441500

Description	Audio unit internal malfunction
Detection condition	Audio unit internal ECU (Tuner peripheral circuit) is faulted.
Fail-safe function	—
Possible cause	Audio unit malfunction
System wiring diagram	—

Diagnostic Procedure

Diagnostic Procedure			
Step	Inspection		Action
1	CONFIRM AUDIO UNIT DTC • Clear the DTC from the audio unit memory. (See CLEARING DTC [AUDIO].) • Perform the audio unit DTC inspection. (See DTC INSPECTION [AUDIO].) • Is the same DTC present?	Yes	Replace the audio unit, then go to the next step. (See AUDIO UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [AUDIO].)
		No	DTC troubleshooting completed.