

---

**ALL POWER WINDOWS OTHER THAN DRIVER-SIDE DO NOT OPERATE USING THE POWER WINDOW MAIN SWITCH [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]**

id090360931300

<b>4</b>	<b>All power windows other than driver's side do not operate using the power window main switch</b>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Open or short circuit in wiring harness between ignition switch (IG1) and power window main switch (IG1).</li><li>• Power window main switch malfunction</li></ul>

**Diagnostic procedure**

<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	<ul style="list-style-type: none"><li>• Switch the ignition ON (engine off or on).</li><li>• Set the power cut-switch to the UNLOCK position.</li><li>• Operate all power windows other than the driver's side using the power window main switch.</li><li>• Do any power windows operate?</li></ul>	Yes	Replace the power window main switch. (See POWER WINDOW MAIN SWITCH REMOVAL/ INSTALLATION.)
		No	Inspect for an open or short circuit in the power window main switch wiring harness (battery power supply). Inspect the power window main switch connector connection. (damage/pulled-out pins, corrosion) Repair or replace if necessary.