

# DTC U3003:16 [REAR VEHICLE MONITORING SYSTEM]

id0902z2888800

<b>System malfunction location</b>	<b>Rear vehicle monitoring control module (RH) low power supply voltage input</b>
<b>Detection condition</b>	<ul style="list-style-type: none"> <li>Power supply circuit voltage of <b>9 V or less</b> is detected in rear vehicle monitoring control module (RH) for <b>1 s or more</b>.</li> </ul>
<b>Fail-safe</b>	<ul style="list-style-type: none"> <li>Inhibits the rear vehicle monitoring system.</li> </ul>
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>DTCs are stored in the PCM.</li> <li>Battery malfunction</li> <li>Generator malfunction</li> <li>Rear vehicle monitoring control module (RH) connector or terminal malfunction</li> <li>Rear vehicle monitoring control module (RH) power supply circuit malfunction <ul style="list-style-type: none"> <li>Short to ground in wiring harness between C/U IG1 15 A fuse and rear vehicle monitoring control module (RH) terminal F</li> <li>C/U IG1 15 A fuse malfunction</li> <li>Open circuit in wiring harness between IG1 relay and rear vehicle monitoring control module (RH) terminal F</li> </ul> </li> <li>Rear vehicle monitoring control module (RH) malfunction</li> </ul>

REAR VEHICLE MONITORING CONTROL MODULE (RH) WIRING HARNESS-SIDE CONNECTOR

## Diagnostic Procedure

Diagnostic Procedure		Inspection		Action	
1	<b>VERIFY PCM DTCs</b> <ul style="list-style-type: none"><li>Perform the DTC inspection for the PCM using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li><li>Is the DTC displayed?</li></ul>	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC TABLE [SKYACTIV-D 2.2].)	No	Go to the next step.
2	<b>INSPECT BATTERY</b> <ul style="list-style-type: none"><li>Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY INSPECTION [SKYACTIV-D 2.2].)</li><li>Is the battery normal?</li></ul>	Yes	Go to the next step.	No	Recharge or replace the battery, then go to Step 6. (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY RECHARGING [SKYACTIV-D 2.2].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)

Step	Inspection	Action	
3	<b>INSPECT GENERATOR</b> <ul style="list-style-type: none"> <li>Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See GENERATOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is the generator normal?</li> </ul>	Yes	Go to the next step.
		No	Replace the generator, then go to Step 6. (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
4	<b>INSPECT REAR VEHICLE MONITORING CONTROL MODULE (RH) CONNECTOR</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Disconnect the rear vehicle monitoring control modules (RH) connector.</li> <li>Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
5	<b>VERIFY REAR VEHICLE MONITORING CONTROL MODULE (RH) POWER SUPPLY VOLTAGE</b> <ul style="list-style-type: none"> <li>Reconnect all the disconnected connectors.</li> <li>Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Display PID VPWR_R using the M-MDS. (See PID/DATA MONITOR INSPECTION [REAR VEHICLE MONITORING SYSTEM].)</li> <li>Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the C/U IG1 15 A fuse. <ul style="list-style-type: none"> <li>If a fuse is burnt out:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which is shorted to ground.</li> <li>Replace the fuse.</li> </ul> </li> <li>If a fuse is damaged:               <ul style="list-style-type: none"> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is normal:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has an open circuit.</li> </ul> </li> </ul> Go to the next step.

Step	Inspection	Action
6	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>• Reconnect all the disconnected connectors.</li> <li>• Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].)</li> <li>• Switch the ignition ON (engine off or on) and wait for <b>1.5 s or more</b>.</li> <li>• Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].)</li> <li>• Is DTC U3003:16 displayed?</li> </ul>	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear vehicle monitoring control module (RH), then go to the next step. (See REAR VEHICLE MONITORING CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
7	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>• Are any other DTCs displayed?</li> </ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR VEHICLE MONITORING SYSTEM].)
		No DTC troubleshooting completed.