

DTC P053B:00	Blow-by heater relay control circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors input voltage from the blow-by heater relay. If the input voltage is below 0.19 V for 1 s, the PCM determines that the blow-by heater relay circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none"> Blow-by heater relay malfunction Short to ground or open circuit in blow-by heater relay power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between main relay terminal C and blow-by heater relay terminal A ENGINE3 15 A fuse malfunction Open circuit in wiring harness between main relay terminal C and blow-by heater relay terminal A Short to ground in wiring harness between blow-by heater relay terminal E and PCM terminal 2C PCM connector or terminals malfunction Open circuit in wiring harness between blow-by heater relay terminal E and PCM terminal 2C PCM malfunction

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
3	INSPECT BLOW-BY HEATER RELAY <ul style="list-style-type: none"> • Switch the ignition off. • Remove the blow-by heater relay. • Inspect the blow-by heater relay. (See RELAY INSPECTION.) • Is there any malfunction? 	Yes	Replace the blow-by heater relay, then go to Step 8.
		No	Go to the next step.
4	INSPECT BLOW-BY HEATER RELAY POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Blow-by heater relay is removed. • Switch the ignition ON (engine off). • Measure the voltage at the blow-by heater relay terminal A (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE3 15 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 8.
5	INSPECT BLOW-BY HEATER RELAY SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Blow-by heater relay is removed. • Switch the ignition off. • Inspect for continuity between blow-by heater relay terminal E (wiring harness-side) and body ground. • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 8.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	INSPECT BLOW-BY HEATER RELAY SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Blow-by heater relay is removed. • Verify that the PCM connector is disconnected. • Inspect for continuity between blow-by heater relay terminal E (wiring harness-side) and PCM terminal 2C (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.