

DTC P007D:00	Boost air temperature sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the input signal from the boost air temperature sensor. If the voltage from the boost air temperature sensor is above 4.90 V for 1 s, the PCM determines that the boost air temperature sensor circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> PCM restricts engine torque. Inhibits the two-stage turbo control. Inhibits the EGR control. Inhibits the diesel particulate filter regeneration control. Inhibits engine-stop by operating the i-stop function. PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Intake air temperature is too low Boost air temperature sensor connector or terminals malfunction Boost air temperature sensor malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between boost air temperature sensor terminal A and PCM terminal 1CM Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Boost air temperature sensor terminal A—PCM terminal 1CM Boost air temperature sensor terminal B—PCM terminal 1AH PCM malfunction
<div style="text-align: center;"> <p>BOOST AIR TEMPERATURE SENSOR WIRING HARNESS-SIDE CONNECTOR</p> <p>PCM WIRING HARNESS-SIDE CONNECTOR</p> </div>	

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT BOOST AIR TEMPERATURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the boost air temperature sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT BOOST AIR TEMPERATURE SENSOR <ul style="list-style-type: none"> Inspect the boost air temperature sensor. (See BOOST AIR TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the boost air temperature sensor, then go to Step 8. (See BOOST AIR TEMPERATURE SENSOR REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	INSPECT BOOST AIR TEMPERATURE SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the boost air temperature sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the boost air temperature sensor terminal A (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
7	INSPECT BOOST AIR TEMPERATURE SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the boost air temperature sensor and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Boost air temperature sensor terminal A— PCM terminal 1CM — Boost air temperature sensor terminal B— PCM terminal 1AH Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
9	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.