

QUICK DIAGNOSTIC CHART [SKYACTIV-D 2.2]

id1103a2000400

×: Applicable
—: Not applicable

Troubleshooting item		Intake air system									
		Intake air system part		Air cleaner			Intake shutter valve		Compressor (small)	Compressor (large)	Compressor bypass solenoid valve
		Air suction/Leakage/Perforation	Clogging	Deformation	Air cleaner element restricted	Non-genuine part installation	Does not fully close (Does not conform to target value)	Clogging, sticking	Improper operation	Improper operation	Improper operation
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	—	—	—	—	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—	—
9*	Acceleration malfunction	—	—	—	—	—	—	—	—	—	—
10*1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Exhaust system					Fuel system			
		EGR valve	EGR cooler		EGR pipe	Diesel particulate filter	Fuel line		Fuel filter	
		Improper operation	Leakage (gas)	Clogging	Clogging	Loss	Leakage	Clogging	Leakage	Clogging
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—
9 [*] 1	Acceleration malfunction	—	—	—	—	—	—	—	—	—
10 ^{*1}	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Fuel system								
		Sedimentor switch		Fuel warmer	Jet pump (4WD)	Supply pump	Suction control valve		Fuel pressure relief valve	
		Always on	Always off	Improper operation	Improper operation	Poor discharge amount	Low adjusted pressure value	High adjusted pressure value	Low adjusted pressure value	High adjusted pressure value
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	—	—	×	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—
9* 1	Acceleration malfunction	—	—	—	×	—	—	—	—	—
10* 1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Fuel system									
		Fuel check valve	Fuel feed valve	Fuel system /Fuel injection	Fuel injector						
		Improper operation	Improper operation	Injection system malfunction (such as leakage)	Open circuit in drive circuit	Short circuit in drive circuit	Leakage	Restricted	Always open	Always close	QR code mismatch
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	—	—	—	—	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—	—
9* 1	Acceleration malfunction	—	—	x	x	x	—	—	—	—	—
10* 1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—

*1 : ATX

x: Applicable
—: Not applicable

Troubleshooting item		Fuel system			Control system					
		Fuel injector	Fuel		PCM				Main relay	
		Injection amount correction miss-match	Low cetane value	Inferior constituent	No initiation	No configuration	No learning	Open circuit in back-up power supply circuit of PCM	Always off	Always on
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	x	x	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Control system (PCM input signal)											
		ECT sensor			IAT sensor No.1			Boost air temperature sensor			IAT sensor No.2		
		High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	×	×	—	×	×	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—	—	—	—
6	Engine does not restart	×	—	—	×	—	—	—	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—	—	—	—
9*	Acceleration malfunction	—	—	—	—	—	—	—	—	—	—	—	—
10*1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Control system (PCM input signal)											
		MAP sensor No.1			MAP sensor No.2			Fuel temperature sensor			Fuel pressure sensor		
		High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	×	—	—	—	—	—	—	—

Troubleshooting item		Control system (PCM input signal)											
		Exhaust gas temperature sensor No.1			Exhaust gas pressure sensor No. 1			Engine oil temperature sensor			Engine oil pressure sensor		
		High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit
10*1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Control system (PCM input signal)											
		Exhaust gas temperature sensor No.2			Exhaust gas temperature sensor No.3			Exhaust gas pressure sensor No. 2			A/F sensor		
		High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit	High input	Low input	Open or short circuit in signal circuit
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	—	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	—	—	—	—	—	—	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—	—	—	—
9* 1	Acceleration malfunction	—	—	—	—	—	—	—	—	—	—	—	—
10* 1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

[illegible]

*1 : ATX

×: Applicable
—: Not applicable

[illegible]

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Control system (PCM output signal)										
		Generator control signal	Starter relay circuit			Blow-by heater relay circuit			Glow control module control signal			
			Open or short circuit	Open circuit in circuit on coil side	Circuit on switch side constantly on	Circuit on switch side constantly off	Open circuit in circuit on coil side	Circuit on switch side constantly on	Circuit on switch side constantly off	Open circuit in power supply circuit	Control signal circuit constantly energizes (FET malfunction)	Control signal always off
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	—	—	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	—	—	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	×	—	×	—	—	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—	—	—
9* 1	Acceleration malfunction	—	—	—	—	—	—	—	—	—	—	—
10* 1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Lubrication system			Cooling system					Charging system	
		Engine oil			Engine coolant passage		Thermostat		Cooling fan motor	Battery	
		Leakage	Clogging	Improper level	Restricted	Leakage	Always open	Always close	Improper operation	Does not charge	No discharge (deterioration)
10 *1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		Charging system							Emission system	ATX	
		Generator			Starter		Glow plug		Catalytic converter (diesel particulate filter)	ATF	
		Low power generation voltage	No power generation	High power generation	Open/short circuit in drive circuit	Internal malfunction	Always off	Always on	Deterioration or loss	Oil cooler restriction	Lack of ATF
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	—	—	—	—	×	—	—	—	—	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—	—	—
4	i-stop function does not operate	—	—	—	—	×	—	—	—	—	—
5	i-stop function operates under no engine-stop conditions	—	—	—	—	—	—	—	—	—	—
6	Engine does not restart	—	—	—	×	—	—	—	—	—	—
7	Limited i-stop function operation time	—	—	—	—	—	—	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—	—	—	—	—
9 *1	Acceleration malfunction	—	—	—	—	—	—	—	—	—	×
10 *1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

[illegible]

*1 : ATX

×: Applicable
—: Not applicable

[illegible]

Troubleshooting item		i-stop								
		False detection of driver-side buckle switch		Instrument cluster malfunction	Number of times i-stop function operates exceeds assured operation amount of components	Ambient temperature sensor	Cabin temperature sensor	Solar radiation sensor	Driver-side air mix actuator malfunction	Driver-side air mix actuator position sensor
		Stuck off	Stuck on			Erratic signal input	Erratic signal input	Erratic signal input		Erratic signal input
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	×	×	×	×	×
9* 1	Acceleration malfunction	—	—	—	—	—	—	—	—	—
10* 1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	—	—	—

*1 : ATX

×: Applicable
—: Not applicable

Troubleshooting item		i-stop							
		Steering angle sensor	Defroster switch malfunction	Low power brake unit load	Power brake unit vacuum sensor	Heater core temperature sensor malfunction	Battery management system malfunction	Brake fluid pressure sensor (built-into DSC HU/CM)	M position switch malfunction (ATX)
		Erratic signal input			Erratic signal input				Erratic signal input
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	×	×	—	×	—	×	×	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—	—	—
4	i-stop function does not operate	×	×	×	×	—	×	×	×
5	i-stop function operates under no engine-stop conditions	×	×	—	×	—	—	×	—
6	Engine does not restart	×	×	—	×	—	×	—	×
7	Limited i-stop function operation time	×	×	×	×	×	×	×	×
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	×	—	—	—
9* 1	Acceleration malfunction	—	—	—	—	—	—	×	—
10* 1	Vehicle moves when accelerating from standstill on slope	—	—	—	—	—	—	×	—

*1 : ATX

×: Applicable

—: Not applicable

Troubleshooting item		i-stop					
		Low-G (XY) sensor (built-into SAS control module)	TFT sensor (ATX)	Electric AT oil pump malfunction (ATX)	DSC HU/CM malfunction	Generator drive belt wear	Ignition switch input (PCM terminal 2H)
		Erratic signal input	Erratic signal input				Stuck on
1	i-stop warning light (amber) illuminates	—	—	—	—	—	—
2	i-stop warning light (amber) flashes	×	×	×	×	×	—
3	i-stop indicator light (green) flashes	—	—	—	—	—	—
4	i-stop function does not operate	×	×	×	×	×	—
5	i-stop function operates under no engine-stop conditions	×	×	—	—	—	—
6	Engine does not restart	—	—	—	—	—	—
7	Limited i-stop function operation time	—	×	—	—	—	—
8	Ineffective operation of A/C during engine stop (i-stop system)	—	—	—	—	—	—
9 [*] 1	Acceleration malfunction	—	—	×	×	×	—
10 [*] *1	Vehicle moves when accelerating from standstill on slope	×	—	×	×	—	—

*1 : ATX