
ROLLOVER VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0116zb804600

Note

- The rollover valve cannot be removed as it is built into the fuel tank.

1. Remove the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)