


DTC P0A94:00 [SKYACTIV-D 2.2]

id0102s4004400

Details On DTCs

DESCRIPTION	DC-DC converter: control circuit signal error	
DETECTION CONDITION	Determination conditions	<ul style="list-style-type: none">• Internal malfunction signal from DC-DC converter via front body control module (FBCM) is received.(CAN/LIN communication).• Input signal from the DC-DC converter limits the pressure increase time.• Input signal from the DC-DC converter does not implement pressure increase after a pressure increase command to the DC-DC converter.
	Preconditions	<ul style="list-style-type: none">• Not applicable
	Drive cycle	<ul style="list-style-type: none">• 1
	Self test type	<ul style="list-style-type: none">• CMDTC self test
	Sensor used	<ul style="list-style-type: none">• Not applicable
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Inhibits engine-stop by operating the i-stop function.	
VEHICLE STATUS WHEN DTCs ARE OUTPUT	<ul style="list-style-type: none">• Flashes i-stop warning light (amber).	
POSSIBLE CAUSE	<ul style="list-style-type: none">• Connector or terminal malfunction of the following parts:<ul style="list-style-type: none">— PCM— Battery— DC-DC converter• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none">— DC-DC converter terminal L—GLOW 80 A fuse— GLOW 80 A fuse and/or DCDC DE 40 A fuse malfunction— Battery positive terminal—GLOW 80 A fuse• Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none">— DC-DC converter terminal L—GLOW 80 A fuse— GLOW 80 A fuse and/or DCDC DE 40 A fuse malfunction— Battery positive terminal—GLOW 80 A fuse• Battery malfunction• DC-DC converter malfunction• Front body control module (FBCM) malfunction• PCM malfunction	

System Wiring Diagram



Function Explanation (DTC Detection Outline)

- The DC-DC converter is equipped with a boost function to stabilize the power supply to the vehicle's electrical devices when the engine is restarted by i-stop. If the DC-DC converter does not operate, the supply voltage to the vehicle's electrical devices decreases. In this diagnostic, the response condition of the DC-DC converter to the boost demand from the PCM, or the boost by the on-board diagnostic function of the DC-DC converter is not detected, and verification of vehicle malfunctions/safety assurance is performed.

Repeatability Verification Procedure

- Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)
- Start the engine.
- Stop the engine by operating the i-stop function.

PID Item/Simulation Item Used In Diagnosis

- Not applicable

Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	PURPOSE: VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
2	PURPOSE: VERIFY IF BATTERY VOLTAGE IS FALSELY RECOGNIZED BY DTC RELATED CAN OR LIN COMMUNICATION <ul style="list-style-type: none"> Perform the PCM and front body control module (FBCM) DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Are DTCs related CAN or LIN communication recorded? 	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-D 2.2].) (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the troubleshooting procedure to perform the procedure from Step 1.

STEP	INSPECTION	RESULTS	ACTION
3	PURPOSE: VERIFY IF THE CURRENT SENSOR IS MISIDENTIFYING MALFUNCTIONS DUE TO A FBCM MALFUNCTION <ul style="list-style-type: none"> Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Is the PENDING CODE for this DTC present? 	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the troubleshooting procedure to perform the procedure from Step 1.

Troubleshooting Diagnostic Procedure

Intention of troubleshooting procedure

- Step 1
 - Perform a unit inspection of the battery.
- Step 2—8
 - Verify if a malfunction is occurring due to a malfunction in each signal transmission and the boost demand line.
- Step 9—10
 - Verify that the primary malfunction is resolved and there are no other malfunctions.

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	INSPECT BATTERY <ul style="list-style-type: none"> Switch the ignition off. Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Recharge or replace the battery, then go to Step 8. (See BATTERY RECHARGING [SKYACTIV-D 2.2].)
		No	Go to the next step.
2	INSPECT DC-DC CONVERTER CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the DC-DC converter connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
3	INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the DC-DC converter connector is disconnected. Measure the voltage at the DC-DC converter terminal L (wiring harness-side). Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the GLOW 80 A fuse and DCDC DE 40 A fuse. <ul style="list-style-type: none"> If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the malfunctioning fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the malfunctioning fuse. If all fuses are normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit. Go to Step 8.
4	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the DC-DC converter connector is disconnected. Inspect for continuity between DC-DC converter terminal F (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 8.
		No	Go to the next step.

STEP	INSPECTION		ACTION
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the DC-DC converter and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the DC-DC converter terminal F (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
7	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between DC-DC converter terminal F (wiring harness-side) and PCM terminal 2P (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Replace the DC-DC converter, and then perform Step 8 again. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.