

DTC B13D0:11 [FRONT BODY CONTROL MODULE (FBCM)]

id0902p2008500

System malfunction location	TNS circuit malfunction
Detection condition	<ul style="list-style-type: none"> The front body control module (FBCM) detects a short to ground in the TNS relay circuit with the ignition switched ON (engine off or on).
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> TNS relay malfunction Front body control module (FBCM) connector or terminal malfunction Short to ground in wiring harness between TNS relay terminal E and front body control module (FBCM) terminal 1I Front body control module (FBCM) malfunction
<p>RELAY AND FUSE BLOCK</p> <p>TNS RELAY (RELAY AND FUSE BLOCK)</p> <p>FBCM</p> <p>FBCM WIRING HARNESS-SIDE CONNECTOR</p> <p>FRONT</p>	

Diagnostic Procedure

Step	Inspection	Action	
1	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN <ul style="list-style-type: none"> Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) Switch the ignition ON (engine off or on). Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Is DTC B13D0:11 displayed? 	Yes	Go to the next step.
		No	Go to Step 6.

Step	Inspection	Action	
2	INSPECT TNS RELAY FOR MALFUNCTION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Remove the TNS relay. Inspect the TNS relay. (See RELAY INSPECTION.) Is the TNS relay normal? 	Yes	Go to the next step.
		No	Replace the TNS relay, then go to Step 5.
3	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the front body control module (FBCM) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
4	INSPECT TNS RELAY CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the TNS relay is removed. Verify that the front body control module (FBCM) connector is disconnected. Inspect for continuity between front body control module (FBCM) terminal 1I (vehicle wiring harness side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness and go to the next step.
		No	Go to the next step.
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) Switch the ignition ON (engine off or on). Operate the light switch in TNS position. Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Is DTC B13D0:11 displayed? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No	Go to the next step.

Step	Inspection		Action
6	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	DTC troubleshooting completed.