

---

## UP SWITCH REMOVAL/INSTALLATION [GW6A-EL, GW6AX-EL]

id0517i2112200

### **Note**

- The up switch is built into the selector lever component.
1. If the up switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)