
DOWN SWITCH REMOVAL/INSTALLATION [FW6A-EL, FW6AX-EL]

id0517h2112300

Note

- The down switch is built into the selector lever component.
1. If the down switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)