
REGULATING VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7217100

Note

- The regulating valve position sensor is integrated in the regulating valve actuator. The regulating valve actuator is integrated in the turbocharger.

1. Remove the turbocharger. (See TURBOCHARGER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)