

**DTC B1087:88 [FRONT BODY CONTROL MODULE (FBCM)]**

id0902p2006700

<b>System malfunction location</b>	<b>LIN communication error</b>
<b>Detection condition</b>	• LIN bus communication line malfunction detected for <b>1 s or more</b>
<b>Fail-safe</b>	—
<b>Possible cause</b>	• Malfunction in LIN bus communication line • Front body control module (FBCM) malfunction
<b>System wiring diagram</b>	—

**Diagnostic Procedure**

<b>Step</b>	<b>Inspection</b>	<b>Action</b>
1	<b>VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN</b> <ul style="list-style-type: none"><li>• Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].)</li><li>• Switch the ignition ON (engine off or on) and wait for <b>1 s or more</b>.</li><li>• Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)</li><li>• Is DTC B1087:88 displayed?</li></ul>	Yes A malfunction in LIN bus communication line can be considered. <ul style="list-style-type: none"><li>• Repair or replace the wiring harness between the DC-DC converter and front body control module (FBCM), then go to the next step.</li><li>• Repair or replace the wiring harness between the current sensor and front body control module (FBCM), then go to the next step.</li></ul>
		No Go to Step 3.
2	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"><li>• Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].)</li><li>• Switch the ignition ON (engine off or on) and wait for <b>1 s or more</b>.</li><li>• Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)</li><li>• Is DTC B1087:88 displayed?</li></ul>	Yes Replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
3	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.