

## DTC P0137:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4300300


### Note

- To determine the malfunctioning part, proceed with the diagnostics from "Function Inspection Using M-MDS".

### Details On DTCs

DESCRIPTION	HO2S circuit low input	
<b>DETECTION CONDITION</b>	Determination conditions	<ul style="list-style-type: none"> <li>A condition in which the HO2S input voltage is less than the specified value continues for the specified period.</li> </ul>
	Preconditions	<ul style="list-style-type: none"> <li>HO2S is activated.</li> <li>The following DTCs are not detected: <ul style="list-style-type: none"> <li>MAF sensor: P0102:00, P0103:00</li> <li>ECT sensor: P0117:00, P0118:00</li> </ul> </li> </ul>
	Malfunction determination period	<ul style="list-style-type: none"> <li>5 s period</li> </ul>
	Drive cycle	<ul style="list-style-type: none"> <li>2</li> </ul>
	Self test type	<ul style="list-style-type: none"> <li>CMDTC self test</li> </ul>
	Sensor used	<ul style="list-style-type: none"> <li>HO2S</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Not applicable</li> </ul>	
<b>VEHICLE STATUS WHEN DTCs ARE OUTPUT</b>	<ul style="list-style-type: none"> <li>Illuminates check engine light.</li> </ul>	
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>HO2S connector or terminals malfunction</li> <li>PCM connector or terminals malfunction</li> <li>Short to ground in wiring harness between HO2S terminal A and PCM terminal 2AI</li> <li>Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>HO2S terminal A—PCM terminal 2AI</li> <li>HO2S terminal B—PCM terminal 2AG</li> </ul> </li> <li>HO2S malfunction</li> <li>PCM malfunction</li> </ul>	

### System Wiring Diagram



am6zzw00011811

### Function Explanation (DTC Detection Outline)

- The PCM detects the oxygen concentration in the exhaust gas based on the HO2S signal. The PCM determines a HO2S signal error based on the condition in which the HO2S input voltage continues to be less than the specified value, and stores a DTC.

### Repeatability Verification Procedure

1. Warm up the engine to allow the engine coolant temperature to reach **80 °C {176 °F} or more**.
2. Start the engine and leave it idling for **1 min**.

#### Note

- Match the engine coolant temperature in the recorded FREEZE FRAME DATA (Mode 2)/snapshot data, the vehicle speed, and engine speed values to the best extent possible while driving the vehicle.
3. Try to reproduce the malfunction by driving the vehicle for **5 min** based on the values in the FREEZE FRAME DATA (Mode 2)/snapshot data.

### PID Item/Simulation Item Used In Diagnosis

- Not applicable

### Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	<b>PURPOSE: VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"><li>• Verify related Service Information availability.</li><li>• Is any related Service Information available?</li></ul>	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"><li>• If the vehicle is not repaired, go to the next step.</li></ul>
		No	Go to the next step.
2	<b>PURPOSE: RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b> <ul style="list-style-type: none"><li>• Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?</li></ul>	Yes	Go to the troubleshooting procedure to perform the procedure from Step 1.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order.  <b>Note</b> <ul style="list-style-type: none"><li>• Recording can be facilitated using the screen capture function of the PC.</li></ul> Go to the troubleshooting procedure to perform the procedure from Step 1.

### Troubleshooting Diagnostic Procedure

#### Intention of troubleshooting procedure

- Step 1—4
  - Perform an inspection of the HO2S and PCM-related connectors and wiring harnesses.
- Step 5
  - Perform a unit inspection of the HO2S.
- Step 6—7
  - Verify that the primary malfunction is resolved and there are no other malfunctions.

STEP	INSPECTION	RESULTS	ACTION
1	<b>PURPOSE: INSPECT HO2S CONNECTOR CONDITION</b> <ul style="list-style-type: none"><li>• Switch the ignition off.</li><li>• Disconnect the HO2S connector.</li><li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li><li>• Is there any malfunction?</li></ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.
2	<b>PURPOSE: INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"><li>• Disconnect the PCM connector.</li><li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li><li>• Is there any malfunction?</li></ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
3	<b>PURPOSE: INSPECT HO2S SIGNAL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Verify that the HO2S and PCM connectors are disconnected.</li> <li>Inspect for continuity between HO2S terminal A (wiring harness-side) and body ground.</li> <li>Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between HO2S terminal A and PCM terminal 2AI. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has a short to ground.</li> </ul> Go to Step 6.
		No	Go to the next step.
4	<b>PURPOSE: INSPECT HO2S CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the HO2S and PCM connectors are disconnected.</li> <li>Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>HO2S terminal A—PCM terminal 2AI</li> <li>HO2S terminal B—PCM terminal 2AG</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>HO2S terminal A—PCM terminal 2AI</li> <li>HO2S terminal B—PCM terminal 2AG</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 6.
5	<b>PURPOSE: DETERMINE INTEGRITY OF HO2S</b> <ul style="list-style-type: none"> <li>Reconnect all disconnected connectors.</li> <li>Inspect the HO2S. (See HEATED OXYGEN SENSOR (HO2S) INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the HO2S, then go to the next step. (See HEATED OXYGEN SENSOR (HO2S) REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
6	<b>PURPOSE: VERIFICATION OF VEHICLE REPAIR COMPLETION</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Implement the repeatability verification procedure. (See Repeatability Verification Procedure.)</li> <li>Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to the next step.
		No	Go to the next step.
7	<b>PURPOSE: VERIFY IF THERE IS ANY OTHER MALFUNCTION</b> <ul style="list-style-type: none"> <li>Is any other DTC or pending code stored?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.