






<b>System malfunction location</b>	<b>Communication error with DC-DC converter</b>
<b>Detection condition</b>	<ul style="list-style-type: none"> <li>The front body control module (FBCM) detects a communication error with the DC-DC converter.</li> </ul>
<b>Fail-safe</b>	—
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>Malfunction in communication line between front body control module (FBCM) and DC-DC converter</li> <li>DC-DC converter connector terminal malfunction</li> <li>Open or short to ground in DC-DC converter power supply circuit <ul style="list-style-type: none"> <li>Short to ground in wiring harness between battery positive terminal and DC-DC converter terminal L</li> <li>DCDC 50 A fuse malfunction (SKYACTIV-G 2.0, SKYACTIV-G 2.5)</li> <li>DCDC DE 40 A fuse malfunction (SKYACTIV-D 2.2)</li> <li>GLOW 80 A fuse malfunction (SKYACTIV-D 2.2)</li> <li>Open circuit in wiring harness between battery positive terminal and DC-DC converter terminal L</li> </ul> </li> <li>Open or short to ground in DC-DC converter power supply circuit <ul style="list-style-type: none"> <li>Short to ground in wiring harness between IG1 relay terminal C and DC-DC converter terminal H</li> <li>C/U IG1 15 A fuse malfunction</li> <li>Open circuit in wiring harness between IG1 relay terminal C and DC-DC converter terminal H</li> </ul> </li> <li>Front body control module (FBCM) connector or terminal malfunction</li> <li>Short to ground in wiring harness between DC-DC converter terminal C and front body control module (FBCM) terminal 2H</li> <li>Open circuit in wiring harness between DC-DC converter terminal C and front body control module (FBCM) terminal 2H</li> <li>DC-DC converter malfunction</li> <li>Front body control module (FBCM) malfunction</li> </ul>

**SKYACTIV-G 2.0, SKYACTIV-G 2.5****SKYACTIV-D 2.2****DC-DC CONVERTER  
WIRING HARNESS-SIDE CONNECTOR****FBCM  
WIRING HARNESS-SIDE CONNECTOR**

2AA	2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A
2AB	2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B



## Diagnostic Procedure

Step	Inspection	Action	
1	<b>VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN</b> <ul style="list-style-type: none"> <li>• Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].)</li> <li>• Switch the ignition ON (engine off or on) and wait for <b>5 s or more</b>.</li> <li>• Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)</li> <li>• Is the DTC U0298:68 displayed?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 10.
2	<b>INSPECT DC-DC CONVERTER CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Disconnect the DC-DC converter connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 9.
3	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR OPEN CIRCUIT OR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC connector is disconnected.</li> <li>• Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Measure the voltage at DC-DC converter terminal L (vehicle wiring harness side).</li> <li>• Is the voltage B+?</li> </ul>	Yes	Go to the next step.
		No	Inspect the following fuses: <ul style="list-style-type: none"> <li>• DCDC 50 A fuse (SKYACTIV-G 2.0, SKYACTIV-G 2.5)</li> <li>• DCDC DE 40 A fuse (SKYACTIV-D 2.2)</li> <li>• GLOW 80 A fuse (SKYACTIV-D 2.2)               <ul style="list-style-type: none"> <li>— If a fuse is burnt out:                   <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which is shorted to ground.</li> <li>• Replace the fuse.</li> </ul> </li> <li>— If a fuse is damaged:                   <ul style="list-style-type: none"> <li>• Replace the fuse.</li> </ul> </li> <li>— If the fuse is normal:                   <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> </li> </ul> </li> </ul> Go to Step 9.

Step	Inspection	Action
4	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR OPEN CIRCUIT OR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC connector is disconnected.</li> <li>• Switch the ignition ON (engine off or on).</li> <li>• Measure the voltage at DC-DC converter terminal H (vehicle wiring harness side).</li> <li>• Is the voltage B+?</li> </ul>	Yes Go to the next step.
		No Inspect the C/U IG1 15 A fuse. <ul style="list-style-type: none"> <li>• If a fuse is burnt out: <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness which is shorted to ground.</li> <li>— Replace the fuse.</li> </ul> </li> <li>• If a fuse is damaged: <ul style="list-style-type: none"> <li>— Replace the fuse.</li> </ul> </li> <li>• If the fuse is normal: <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness which has an open circuit.</li> </ul> </li> </ul> Go to Step 9.
5	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Disconnect the front body control module (FBCM) connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 9.
6	<b>INSPECT DC-DC CONVERTER LIN COMMUNICATION CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between DC-DC converter terminal C (vehicle wiring harness) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes Repair or replace the wiring harness, then go to Step 9.
		No Go to the next step.
7	<b>INSPECT DC-DC CONVERTER LIN COMMUNICATION CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect the wiring harness for continuity between DC-DC converter terminal C (vehicle wiring harness side) and front body control module (FBCM) terminal 2H (vehicle wiring harness side).</li> <li>• Is there continuity?</li> </ul>	Yes Go to the next step.
		No Repair or replace the wiring harness, then go to Step 9.
8	<b>INSPECT DC-DC CONVERTER</b> <ul style="list-style-type: none"> <li>• Inspect the DC-DC converter. (See DC-DC CONVERTER INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DC-DC CONVERTER INSPECTION [SKYACTIV-D 2.2].)</li> <li>• Is the DC-DC converter normal?</li> </ul>	Yes Go to the next step.
		No Replace the DC-DC converter, then go to the next step. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)

Step	Inspection	Action
9	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>• Reconnect all the disconnected connectors.</li> <li>• Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].)</li> <li>• Switch the ignition ON (engine off or on) and wait for <b>5 s or more</b>.</li> <li>• Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)</li> <li>• Is the DTC U0298:68 displayed?</li> </ul>	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
10	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>• Are any other DTCs displayed?</li> </ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.