
VEHICLE MOVES IN P POSITION, OR PARKING GEAR DOES NOT DISENGAGE WHEN P IS DISENGAGED
[FW6A-EL, FW6AX-EL]

id050317100600

TROUBLESHOOTING ITEM	Vehicle moves in P position, or parking gear does not disengage when P is disengaged
DESCRIPTION	<ul style="list-style-type: none">• Vehicle rolls when on a downward slope in P position.• Vehicle does not move in D, M and R position when accelerator pedal is depressed, and engine remains in stalled condition.
POSSIBLE CAUSE	1. Parking mechanism malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	INSPECT PARKING MECHANISM FOR MALFUNCTION <ul style="list-style-type: none">• When the vehicle is stopped on a flat, level road and the engine is off, does the vehicle move when pushed? (In D, N or R position with the brake pedal released.)	Yes Symptom troubleshooting is completed.
		No Replace the parking mechanism. (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [FW6A-EL].) (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [FW6AX-EL].)