

**DTC B1008:02 [FRONT BODY CONTROL MODULE (FBCM)]**

id0902p2006400

<b>System malfunction location</b>	Windshield wiper control signal mismatch
<b>Detection condition</b>	• The front body control module (FBCM) receives error signals from the start stop unit with the ignition switched ON (engine off or on).
<b>Fail-safe</b>	—
<b>Possible cause</b>	• Start stop unit malfunction • Front body control module (FBCM) malfunction
<b>System wiring diagram</b>	—

**Diagnostic Procedure**

Step	Inspection	Action
1	<b>PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS START STOP UNIT</b> • Clear DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Switch the ignition ON (engine off or on). • Perform the DTC inspection for the front body control module (FBCM) using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is DTC B1008:02 displayed?	Yes Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to Step 3.
2	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> • Clear the front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Switch the ignition ON (engine off or on). • Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is DTC B1008:02 displayed?	Yes replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
3	<b>VERIFY IF OTHER DTCs DISPLAYED</b> • Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.