

**DTC U0423:68 [LASER SENSOR]**

id0402c4895300

DTC	U0423:68	Abnormal message from instrument cluster
<b>DETECTION CONDITION</b>	• Correct data cannot be received from instrument cluster	
<b>FAIL-SAFE FUNCTION</b>	• Inhibits the smart city brake support (SCBS) controls. • Illuminates the master warning light • The message "SCBS Inspection Required" is indicated in the display.	
<b>POSSIBLE CAUSE</b>	• Instrument cluster malfunction	
<b>SYSTEM WIRING DIAGRAM</b>	—	

**Diagnostic procedure**

STEP	INSPECTION		ACTION
1	<b>INSPECT FOR INSTRUMENT CLUSTER MALFUNCTION</b> • Switch the ignition to off. • Using the M-MDS, perform the DTC inspection for the instrument cluster . (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs detected?	Yes	Go to applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
2	<b>VERIFY THAT THE SAME DTC IS NOT PRESENT</b> • Clear the DTCs from the memory. (See ON-BOARD DIAGNOSIS [LASER SENSOR].) • Are the same DTCs present?	Yes	Configure the instrument cluster, then repeat the inspection from Step 1. (See INSTRUMENT CLUSTER CONFIGURATION (USING READ/WRITE FUNCTION).) (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) If the malfunction recurs, replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Go to the next step.
3	<b>VERIFY THAT NO OTHER DTCS ARE PRESENT</b> • Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [LASER SENSOR].)
		No	DTC troubleshooting completed.