

---

## TIRE PRESSURE MONITORING SYSTEM SET SWITCH REMOVAL/INSTALLATION

id021200205000

### Note

- The tire pressure monitoring system (TPMS) set switch is integrated with the cluster switch.
- Refer to SWITCH PANEL REMOVAL/INSTALLATION to remove the cluster switch.

1. Remove the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)
2. Install in the reverse order of removal.