


NO.9 ACCELERATION MALFUNCTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id1103a5001400

9	ACCELERATION MALFUNCTION
DESCRIPTION	<ul style="list-style-type: none"> Acceleration from i-stop is not smooth. Suppresses (shock) when accelerating vehicle from i-stop. Engine vibration increases when engine is restarted.
POSSIBLE CAUSE	<p>Note</p> <ul style="list-style-type: none"> MT vehicles are not included because the driver releases the brake pedal and depresses the clutch pedal to accelerate. <p>ATX system malfunction</p> <ul style="list-style-type: none"> Electric AT oil pump malfunction (operation malfunction, insufficient pressure) <ul style="list-style-type: none"> Electric AT oil pump relay malfunction (stuck open) Short to ground or open circuit in electric AT oil pump relay power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between MAIN 200 A fuse and electric AT oil pump relay terminal A Short to ground in wiring harness between MAIN 200 A fuse and electric AT oil pump relay terminal D MAIN 200 A fuse and/or AT PUMP 15 A fuse malfunction Open circuit in wiring harness between battery positive terminal and electric AT oil pump relay terminal A Open circuit in wiring harness between battery positive terminal and electric AT oil pump relay terminal D Electric AT oil pump connector or terminals malfunction Short to ground in wiring harness between electric AT oil pump relay terminal C and electric AT oil pump terminal D Open circuit in wiring harness between electric AT oil pump terminal A and body ground Open circuit in wiring harness between electric AT oil pump relay terminal C and electric AT oil pump terminal D TCM connector or terminals malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> Electric AT oil pump relay terminal E—TCM terminal K Electric AT oil pump terminal C—TCM terminal L Electric AT oil pump terminal B—TCM terminal N Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Electric AT oil pump relay terminal E—TCM terminal K Electric AT oil pump terminal C—TCM terminal L Electric AT oil pump terminal B—TCM terminal N Electric AT oil pump malfunction TCM malfunction <p>• ATX malfunction</p> <p>Hill launch assist function system (DSC) malfunction</p> <ul style="list-style-type: none"> False detection of inclination angle (cannot calculate correct road slope) <ul style="list-style-type: none"> Low-G (XY) sensor (built-into SAS control module) malfunction (In this case, the SAS control module records DTCs C0061:29 and C0062:29.) Low-G (XY) sensor (built-into SAS control module) initialization malfunction False detection of brake fluid pressure <ul style="list-style-type: none"> Brake fluid pressure sensor (built-into DSC HU/CM) malfunction Cannot maintain brake fluid pressure <ul style="list-style-type: none"> DSC HU/CM malfunction



Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	DETERMINE IF MALFUNCTION CAUSED BY ATX BODY <ul style="list-style-type: none"> Compare the malfunction symptom with the i-stop system stop condition. Is there any shock or slippage during acceleration with the i-stop system disabled? 	Yes	Perform the applicable symptom troubleshooting procedure. (See SYMPTOM TROUBLESHOOTING ITEM TABLE [FW6A-EL, FW6AX-EL].)
		No	Go to the next step.
2	VERIFY DTC <ul style="list-style-type: none"> Retrieve the PCM, TCM, DSC HU/CM, SAS control module DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FW6A-EL, FW6AX-EL].) (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) (See DTC INSPECTION.) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FW6A-EL, FW6AX-EL].) (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) (See DTC TABLE.)
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
3	DETERMINE IF MALFUNCTION CAUSE IS BRAKE FLUID PRESSURE SENSOR SIGNAL OR OTHER <ul style="list-style-type: none"> Put the vehicle in an i-stop condition (engine stopped). Monitor the PCM PID BFP using the M-MDS while the brake is depressed and held with the i-stop function operating. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) Does the monitoring value change? 	Yes	Brake fluid pressure sensor (built-into DSC HU/CM) or DSC HU/CM brake pressure hold function malfunction. • Replace the DSC HU/CM. (See DSC HU/CM REMOVAL/INSTALLATION.)
		No	Go to the next step.
4	INSPECT ELECTRIC AT OIL PUMP RELAY <ul style="list-style-type: none"> Switch the ignition off. Remove the electric AT oil pump relay. Inspect the electric AT oil pump relay. (See RELAY INSPECTION.) Is there any malfunction? 	Yes	Replace the electric AT oil pump relay.
		No	Go to the next step.
5	INSPECT ELECTRIC AT OIL PUMP RELAY POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Electric AT oil pump relay is removed. Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> Electric AT oil pump relay terminal A Electric AT oil pump relay terminal D Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and AT PUMP 15 A fuse. • If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the malfunctioning fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the malfunctioning fuse. • If all fuses are normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit.
6	INSPECT ELECTRIC AT OIL PUMP CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the electric AT oil pump connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals.
		No	Go to the next step.
7	INSPECT ELECTRIC AT OIL PUMP POWER SUPPLY CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Electric AT oil pump relay is removed. Verify that the electric AT oil pump connector is disconnected. Inspect for continuity between electric AT oil pump relay terminal C (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground.
		No	Go to the next step.
8	INSPECT ELECTRIC AT OIL PUMP GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Electric AT oil pump relay is removed. Verify that the electric AT oil pump connector is disconnected. Inspect for continuity between electric AT oil pump terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit.
9	INSPECT ELECTRIC AT OIL PUMP POWER SUPPLY CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Electric AT oil pump relay is removed. Verify that the electric AT oil pump connector is disconnected. Inspect for continuity between electric AT oil pump relay terminal C (wiring harness-side) and electric AT oil pump terminal D (wiring harness-side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit.

STEP	INSPECTION	RESULTS	ACTION
10	INSPECT TCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the TCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals.
		No	Go to the next step.
11	INSPECT TCM CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Electric AT oil pump relay is removed. • Verify that the electric AT oil pump and TCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Electric AT oil pump relay terminal E — Electric AT oil pump terminal C — Electric AT oil pump terminal B • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground.
		No	Go to the next step.
12	INSPECT TCM CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Electric AT oil pump relay is removed. • Verify that the electric AT oil pump and TCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Electric AT oil pump relay terminal E—TCM terminal K — Electric AT oil pump terminal C—TCM terminal L — Electric AT oil pump terminal B—TCM terminal N • Is there continuity? 	Yes	Replace the electric AT oil pump. (See ELECTRIC AT OIL PUMP REMOVAL/INSTALLATION [FW6A-EL, FW6AX-EL].)
		No	Repair or replace the wiring harness for a possible open circuit.
13	Verify the test results. <ul style="list-style-type: none"> • If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. <ul style="list-style-type: none"> — If the vehicle is repaired, troubleshooting is completed. — If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) 		