

DTC P2507:00 [SKYACTIV-G 2.0]

id0102h1709800

DTC P2507:00	PCM battery voltage low input
DETECTION CONDITION	<ul style="list-style-type: none">The PCM monitors the voltage of backup battery positive terminal. If the PCM detects that the battery positive terminal voltage is below 6 V for 5 s, the PCM determines that the backup voltage circuit has a malfunction. Diagnostic support note <ul style="list-style-type: none">This is a continuous monitor (CCM).The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.FREEZE FRAME DATA (Mode 2)/Snapshot data is available.The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none">Battery malfunctionShort to ground or open circuit in backup voltage circuit<ul style="list-style-type: none">Short to ground in wiring harness between MAIN 200 A fuse and PCM terminal 2OMAIN 200 A fuse and/or ENG.+B 7.5 A fuse malfunctionOpen circuit in wiring harness between battery positive terminal and PCM terminal 2OPCM connector or terminals malfunctionPCM malfunction

③

BATTERY

⊖

⊕

○

○

④

④

④

⑤

MAIN 200 A

ENG.+B 7.5 A

2O

PCM

⏏

PCM WIRING HARNESS-SIDE CONNECTOR

2BE

2AZ

2AU

2AP

2AK

2BF

2BA

2AV

2AQ

2AL

2BG

2BB

2AW

2AR

2AM

2BH

2BC

2AX

2AS

2AN

2BD

2AY

2AT

2AO

2AE

2AA

2W

2S

2O

2K

2G

2C

2AF

2AB

2X

2T

2P

2L

2H

2D

2AI

2AG

2AC

2Y

2U

2Q

2M

2I

2E

2A

2AJ

2AH

2AD

2Z

2V

2R

2N

2J

2F

2B

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

2A

2B

2C

2D

2E

2F

2G

2H

2I

2J

2K

2L

2M

2N

2O

2P

2Q

2R

2S

2T

2U

2V

2W

2X

2Y

2Z

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"> If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT BATTERY <ul style="list-style-type: none"> Switch the ignition to off. Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0].) (See BATTERY INSPECTION [SKYACTIV-G 2.0 (WITHOUT i-stop)].) Is there any malfunction? 	Yes	Recharge or replace the battery, then go to Step 6. (See BATTERY RECHARGING [SKYACTIV-G 2.0].) (See BATTERY RECHARGING [SKYACTIV-G 2.0 (WITHOUT i-stop)].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
4	INSPECT BACKUP VOLTAGE CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Access the VPWR PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) • Verify the VPWR PID value. • Is the VPWR PID value B+? 	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and ENG.+B 7.5 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the malfunctioning fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the malfunctioning fuse. • If all fuses are normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 6.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	Go to the next step.
6	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine and warm it up completely. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
7	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.