

DTC P0097:00	IAT sensor No.2 circuit low input
DETECTION CONDITION	<ul style="list-style-type: none">• If the PCM detects that the IAT sensor No.2 voltage at the PCM terminal 2N is 0.10 V or less for 1 s with the following condition met, the PCM determines that the IAT sensor No.2 circuit voltage is low. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none">— Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none">• This is a continuous monitor (CCM).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Inhibits the EGR control.• Inhibits engine-stop by operating the i-stop function.• PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none">• Intake air temperature is too high• IAT sensor No.2 connector or terminals malfunction• IAT sensor No.2 malfunction• Short to ground in wiring harness between IAT sensor No.2 terminal A and PCM terminal 2N• PCM connector or terminals malfunction• IAT sensor No.2 signal circuit and ground circuit are shorted to each other• PCM malfunction

④

IAT SENSOR NO.2

A

B

③

③

⑤

⑦

⑥

⑥

⑦

PCM

2N

2AV

IAT SENSOR NO.2

WIRING HARNESS-SIDE

CONNECTOR

B

A

PCM WIRING HARNESS-SIDE CONNECTOR

2BE

2AZ

2AU

2AP

2AK

2BF

2BA

2AV

2AQ

2AL

2BG

2BB

2AW

2AR

2AM

2BH

2BC

2AX

2AS

2AN

2BD

2AY

2AT

2AO

2AE

2AA

2W

2S

2O

2K

2G

2C

2AF

2AB

2X

2T

2P

2L

2H

2D

2AI

2AG

2AC

2Y

2U

2Q

2M

2I

2E

2A

2AJ

2AH

2AD

2Z

2V

2R

2N

2J

2F

2B

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
3	INSPECT IAT SENSOR NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the IAT sensor No.2 connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT IAT SENSOR NO.2 <ul style="list-style-type: none"> • Inspect the IAT sensor No.2. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the IAT sensor No.2, then go to Step 8. (See INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	INSPECT IAT SENSOR NO.2 SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the IAT sensor No.2 connector is disconnected. • Switch the ignition off. • Inspect for continuity between IAT sensor No.2 terminal A (wiring harness-side) and body ground. • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 8.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	INSPECT IAT SENSOR NO.2 SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the IAT sensor No.2 and PCM connectors are disconnected. • Inspect for continuity between IAT sensor No.2 terminals A and B (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to the next step.
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.