

STEP	INSPECTION	RESULTS	ACTION
3	VERIFY DTC <ul style="list-style-type: none"> Retrieve the PCM and instrument cluster DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC INSPECTION [INSTRUMENT CLUSTER].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
4	INSPECT OIL PRESSURE SWITCH CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the oil pressure switch connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals.
		No	Go to the next step.
5	INSPECT OIL PRESSURE SWITCH CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the oil pressure switch connector is disconnected. Inspect for continuity between oil pressure switch terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals.
		No	Go to the next step.
7	INSPECT OIL PRESSURE SWITCH SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the oil pressure switch and PCM connectors are disconnected. Inspect for continuity between oil pressure switch terminal A (wiring harness-side) and PCM terminal 1P (wiring harness-side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit.
8	INSPECT ENGINE OIL PRESSURE <ul style="list-style-type: none"> Inspect the engine oil pressure. (See OIL PRESSURE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the oil pump, then go to the next step. (See OIL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Replace the oil pressure switch, then go to the next step. (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
9	Verify the test results. <ul style="list-style-type: none"> If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. <ul style="list-style-type: none"> If the vehicle is repaired, troubleshooting is completed. If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) 		