


**DTC U1007:00 [SKYACTIV-G 2.0]**

id0102h1855400

<b>DTC U1007:00</b>	<b>CAN/LIN communication system: current sensor information communication error with front body control module (FBCM)</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>• PCM detects a current sensor information communication error from front body control module (FBCM).</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>• This is a continuous monitor (other).</li><li>• The check engine light does not illuminate.</li><li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.</li><li>• The DTC is stored in the PCM memory.</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>• Inhibits engine-stop by operating the i-stop function.</li><li>• Inhibits a part of the generator output control.</li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Communication line between current sensor and front body control module (FBCM) malfunction</li><li>• Communication line between front body control module (FBCM) and PCM malfunction</li><li>• Current sensor connector or terminals malfunction</li><li>• Short to ground or open circuit in current sensor power supply circuit<ul style="list-style-type: none"><li>— Short to ground in wiring harness between MAIN 200 A fuse and current sensor terminal A</li><li>— MAIN 200 A fuse and/or ENG.+B 7.5 A fuse malfunction</li><li>— Open circuit in wiring harness between battery positive terminal and current sensor terminal A</li></ul></li><li>• Front body control module (FBCM) connector or terminals malfunction</li><li>• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— Current sensor terminal B—Front body control module (FBCM) terminal 2E</li><li>— Front body control module (FBCM) terminal 2P—PCM terminal 2AK</li><li>— Front body control module (FBCM) terminal 2N—PCM terminal 2AL</li></ul></li><li>• Open circuit in wiring harness between current sensor terminal B and front body control module (FBCM) terminal 2E</li><li>• PCM connector or terminals malfunction</li><li>• Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— Front body control module (FBCM) terminal 2P—PCM terminal 2AK</li><li>— Front body control module (FBCM) terminal 2N—PCM terminal 2AL</li></ul></li><li>• Current sensor malfunction</li><li>• Front body control module (FBCM) malfunction</li><li>• PCM malfunction</li></ul>



### Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> • Switch the ignition to off, then to ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
3	<b>INSPECT CURRENT SENSOR CONNECTOR CONDITION</b>  <b>Note</b> <ul style="list-style-type: none"> <li>• Always disconnect current sensor connector before disconnecting the negative battery cable.</li> <li>• Switch the ignition to off.</li> <li>• Disconnect the current sensor connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 13.
		No	Go to the next step.
4	<b>INSPECT CURRENT SENSOR POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the current sensor connector is disconnected.</li> <li>• Measure the voltage at the current sensor terminal A (wiring harness-side).</li> <li>• Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and ENG.+B 7.5 A fuse. <ul style="list-style-type: none"> <li>• If the fuse is blown:               <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness for a possible short to ground.</li> <li>— Replace the malfunctioning fuse.</li> </ul> </li> <li>• If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>— Replace the malfunctioning fuse.</li> </ul> </li> <li>• If all fuses are normal:               <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness for a possible open circuit.</li> </ul> </li> </ul> Go to Step 13.
5	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the front body control module (FBCM) connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 13.
		No	Go to the next step.
6	<b>INSPECT CURRENT SENSOR SIGNAL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the current sensor and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between current sensor terminal B (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 13.
		No	Go to the next step.
7	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM) CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the current sensor and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground:               <ul style="list-style-type: none"> <li>— Front body control module (FBCM) terminal 2P</li> <li>— Front body control module (FBCM) terminal 2N</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness for a possible short to ground.</li> </ul> If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)</li> </ul> Go to Step 13.
		No	Go to the next step.
8	<b>INSPECT CURRENT SENSOR SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the current sensor and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between current sensor terminal B (wiring harness-side) and front body control module (FBCM) terminal 2E (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 13.

STEP	INSPECTION		ACTION
9	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 13.
		No	Go to the next step.
10	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM) CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the current sensor, front body control module (FBCM) and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Front body control module (FBCM) terminal 2P—PCM terminal 2AK</li> <li>— Front body control module (FBCM) terminal 2N—PCM terminal 2AL</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 13.
11	<b>INSPECT CURRENT SENSOR</b> <ul style="list-style-type: none"> <li>• Inspect the current sensor. (See CURRENT SENSOR INSPECTION [SKYACTIV-G 2.0].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the current sensor, then go to Step 13. (See CURRENT SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
12	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM)</b> <ul style="list-style-type: none"> <li>• Inspect the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) INSPECTION.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No	Go to the next step.
13	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Make sure to reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].)</li> <li>• Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
14	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.