


# DTC P0102:00 [SKYACTIV-D 2.2]

id0102s4700900

<b>DTC P0102:00</b>	<b>MAF sensor circuit low input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>• If the PCM detects that the MAF sensor voltage at the PCM terminal 2U is <b>0.10 V or less</b> for <b>5 s</b> with the following condition met, the PCM determines that the MAF sensor circuit voltage is low.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>— Battery voltage: <b>8—20 V</b></li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>• This is a continuous monitor (CCM).</li> <li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>• DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>• PCM restricts engine torque.</li> <li>• Inhibits the EGR control.</li> <li>• Inhibits the diesel particulate filter regeneration control.</li> <li>• The fast idle up correction for the idle speed control is inhibited.</li> <li>• Inhibits engine-stop by operating the i-stop function.</li> <li>• PCM restricts engine-transaxle integration control.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• MAF sensor/IAT sensor No.1 connector or terminals malfunction</li> <li>• Short to ground or open circuit in MAF sensor power supply circuit <ul style="list-style-type: none"> <li>— Short to ground in wiring harness between ENGINE1 15 A fuse and MAF sensor/IAT sensor No.1 terminal E</li> <li>— ENGINE1 15 A fuse malfunction</li> <li>— Open circuit in wiring harness between main relay terminal C and MAF sensor/IAT sensor No.1 terminal E</li> </ul> </li> <li>• Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>— MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2AC</li> <li>— MAF sensor/IAT sensor No.1 terminal C—PCM terminal 2U</li> </ul> </li> <li>• PCM connector or terminals malfunction</li> <li>• MAF sensor signal circuit and ground circuit are shorted to each other</li> <li>• Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>— MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2AC</li> <li>— MAF sensor/IAT sensor No.1 terminal C—PCM terminal 2U</li> </ul> </li> <li>• MAF sensor malfunction</li> <li>• PCM malfunction</li> </ul>



### Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	<b>INSPECT MAF SENSOR/IAT SENSOR NO.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the MAF sensor/IAT sensor No.1 connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	<b>INSPECT MAF SENSOR POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>Switch the ignition ON (engine off).</li> <li>Measure the voltage at the MAF sensor/IAT sensor No.1 terminal E (wiring harness-side).</li> <li>Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the ENGINE1 15 A fuse. <ul style="list-style-type: none"> <li>If the fuse is blown:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible short to ground.</li> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is normal:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible open circuit.</li> </ul> </li> </ul> Go to Step 10.

STEP	INSPECTION		ACTION
5	<b>INSPECT MAF SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— MAF sensor/IAT sensor No.1 terminal D</li> <li>— MAF sensor/IAT sensor No.1 terminal C</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness for a possible short to ground.</li> </ul> If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to Step 10.
		No	Go to the next step.
6	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
7	<b>INSPECT MAF SENSOR SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>• Verify that the MAF sensor/IAT sensor No.1 and PCM connectors are disconnected.</li> <li>• Inspect for continuity between MAF sensor/IAT sensor No.1 terminals C and B (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 10.
		No	Go to the next step.
8	<b>INSPECT MAF SENSOR CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the MAF sensor/IAT sensor No.1 and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2AC</li> <li>— MAF sensor/IAT sensor No.1 terminal C—PCM terminal 2U</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or the replace the wiring harness for a possible open circuit, then go to Step 10.
9	<b>INSPECT MAF SENSOR</b> <ul style="list-style-type: none"> <li>• Reconnect all disconnected connectors.</li> <li>• Inspect the MAF sensor. (See MASS AIR FLOW (MAF) SENSOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the MAF sensor/IAT sensor No.1, then go to the next step. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
10	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to the next step.
		No	Go to the next step.
11	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.