

DTC U3000:49 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4015500

System malfunction location	Rear body control module (RBCM) internal malfunction
Detection condition	• Malfunction inside rear body control module (RBCM) detected.
Fail-safe	—
Possible cause	• Rear body control module (RBCM) malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS REAR BODY CONTROL MODULE (RBCM) <ul style="list-style-type: none">• Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)• Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)• Is DTC U3000:49 displayed?	Yes Replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].)
		No DTC troubleshooting completed.