

NO.1 TPMS WARNING LIGHT ILLUMINATES

id020300101000

Caution

- The tire pressure monitoring system warning light illuminates according to the decrease in a tire air pressure (tire pressure monitoring system is normal).
- The No.1 TPMS WARNING LIGHT ILLUMINATES the diagnostic procedure if the tire pressure monitoring system warning light illuminated due to a decrease in a tire pressure although the tire pressure monitoring system is normal.

Possible malfunction

- The air pressure of a tire has decreased. (Tire pressure monitoring system normal)
- The tire pressure monitoring warning light illuminates based on mis-use prevention logic. (Tire pressure monitoring system normal)

Diagnostic Procedure

Note


- The diagnostic procedure differs depending on the DSC HU/CM specification.
- Before performing the diagnostic, verify the DSC HU/CM specification to prevent incorrect diagnosis.
- The DSC HU/CM specification can be verified by the first four digits of the part number indicated on the label adhered to the DSC HU/CM.

First 4 digits of part number for Type A DSC HU/CM

- K011
- K0Y1

First 4 digits of part number for Type B DSC HU/CM

- KJ11
- KJY1



ac5wzw00006259

Diagnostic procedure for Type A DSC HU/CM

Step	Inspection	Results	Action
1	TIRE PRESSURE INSPECTION • Inspect tire pressures while the tires are cold. (See WHEEL AND TIRE SPECIFICATION.) • Are the tire pressures at the specification?	Yes	Go to the next step.
		No	Adjust the tire pressures to the specification while the tires are cold.
2	TIRE PRESSURE MONITORING SYSTEM INITIALIZATION • Perform tire pressure monitoring system initialization. (See TIRE PRESSURE MONITORING SYSTEM INITIALIZATION PROCEDURE.) • Was the tire pressure monitoring system initialization performed?	Yes	Go to the next step.
		No	Perform the tire pressure monitoring system initialization. (See TIRE PRESSURE MONITORING SYSTEM INITIALIZATION PROCEDURE.)
3	VERIFY MIS-USE PREVENTION LOGIC (FIRST TIME) • Drive the vehicle for several minutes after the tire pressure monitoring warning light turns off. • Does the tire pressure monitoring warning light illuminate?	Yes	Go to the next step.
		No	The tire pressure monitoring system is normal.

Step	Inspection	Results	Action
4	TIRE PRESSURE MONITORING SYSTEM INITIALIZATION <ul style="list-style-type: none"> Perform the tire pressure monitoring system initialization. (See TIRE PRESSURE MONITORING SYSTEM INITIALIZATION PROCEDURE.) Was the tire pressure monitoring system initialization performed? 	Yes	Go to the next step.
		No	Perform the tire pressure monitoring system initialization. (See TIRE PRESSURE MONITORING SYSTEM INITIALIZATION PROCEDURE.)
5	MIS-USE PREVENTION LOGIC VERIFICATION (SECOND TIME) <ul style="list-style-type: none"> Drive the vehicle for several minutes after the tire pressure monitoring warning light turns off. Does the tire pressure monitoring warning light illuminate? 	Yes	Go to the next step.
		No	The tire pressure monitoring system is normal.
6	TIRE PRESSURE MONITORING SYSTEM INITIALIZATION <ul style="list-style-type: none"> Perform the tire pressure monitoring system initialization. (See TIRE PRESSURE MONITORING SYSTEM INITIALIZATION PROCEDURE.) Was the tire pressure monitoring system initialization performed? 	Yes	Go to the next step.
		No	Perform the tire pressure monitoring system initialization. (See TIRE PRESSURE MONITORING SYSTEM INITIALIZATION PROCEDURE.)
7	MIS-USE PREVENTION LOGIC VERIFICATION (THIRD TIME) <ul style="list-style-type: none"> Drive the vehicle for several minutes after the tire pressure monitoring warning light turns off. Does the tire pressure monitoring warning light illuminate? 	Yes	Inspect the tires and wheels for air leakage.
		No	The tire pressure monitoring system is normal.

Diagnostic procedure for Type B DSC HU/CM

Step	Inspection	Results	Action
1	TIRE PRESSURE INSPECTION <ul style="list-style-type: none"> Inspect tire pressures while the tires are cold. (See WHEEL AND TIRE SPECIFICATION.) Are the tire pressures at the specification? 	Yes	Go to the next step.
		No	Adjust the tire pressures to the specification while the tires are cold.
2	TIRE PRESSURE MONITORING SYSTEM INITIALIZATION <ul style="list-style-type: none"> Perform tire pressure monitoring system initialization. Connect the M-MDS (IDS) to DLC-2. After the vehicle is identified, select the following items from the initial screen of the IDS. <ol style="list-style-type: none"> Select "Chassis" Select "ABS/DSC" Select "TPMS Reset" Was the tire pressure monitoring system initialization performed? 	Yes	Go to the next step.
		No	Perform the tire pressure monitoring system initialization.
3	TIRE PRESSURE MONITORING SYSTEM WARNING LIGHT VERIFICATION <ul style="list-style-type: none"> Drive the vehicle for several minutes after the tire pressure monitoring system warning light turns off. Does the tire pressure monitoring system warning light illuminate? 	Yes	Inspect the tires and wheels for air leakage.
		No	The tire pressure monitoring system is normal.