

DTC B1079:13 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4012600

System malfunction location	Bonnet latch switch circuit malfunction
Detection condition	<ul style="list-style-type: none"> Rear body control module (RBCM) detects open circuit in bonnet latch switch circuit.
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> Bonnet latch switch connector or terminal malfunction Open circuit in wiring harness between bonnet latch switch terminal B and body ground Bonnet latch switch malfunction Rear body control module (RBCM) connector or terminal malfunction Open circuit in wiring harness between rear body control module (RBCM) terminal 3L and bonnet latch switch terminal A Rear body control module (RBCM) malfunction

RBCM

RBCM WIRING HARNESS-SIDE CONNECTOR

BONNET LATCH SWITCH WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

Step	Inspection	Action	
1	VERIFY REAR BODY CONTROL MODULE (RBCM) DTCs AGAIN <ul style="list-style-type: none">• Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)• Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)• Is DTC B1079:13 displayed?	Yes	Go to the next step.
		No	Go to Step 8.

Step	Inspection	Action	
2	INSPECT BONNET LATCH SWITCH CONNECTOR <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Disconnect the bonnet latch switch connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
3	INSPECT BONNET LATCH SWITCH GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the bonnet latch switch connector is disconnected. Inspect for continuity between bonnet latch switch terminal B (vehicle wiring harness side) and body ground. Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness which has an open circuit, then go to Step 7.
4	INSPECT BONNET LATCH SWITCH <ul style="list-style-type: none"> Inspect the bonnet latch switch. (See BONNET LATCH SWITCH INSPECTION.) Is the bonnet latch switch normal? 	Yes	Go to the next step.
		No	Replace the bonnet latch switch, then go to Step 7. (See BONNET LATCH AND RELEASE LEVER REMOVAL/INSTALLATION.)
5	INSPECT REAR BODY CONTROL MODULE (RBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the rear body control module (RBCM) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
6	INSPECT BONNET LATCH SWITCH CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the bonnet latch switch and rear body control module (RBCM) connectors are disconnected. Inspect the wiring harness for an open circuit between rear body control module (RBCM) terminal 3L (vehicle wiring harness side) and bonnet latch switch terminal A (vehicle wiring harness side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness which has an open circuit, then go to the next step.

Step	Inspection	Action
7	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].) • Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) • Is DTC B1079:13 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].)
		No DTC troubleshooting completed.