

# DTC P0882:00 [FW6A-EL, FW6AX-EL]

id050227823100

<b>DTC P0882:00</b>	<b>TCM power supply voltage low</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>Under the following conditions, the TCM power supply voltage is <b>8—10.5 V or less</b> (varies with ATF temperature): <ul style="list-style-type: none"> <li><b>5 s or more</b> has elapsed or battery voltage exceeds <b>11 V or more</b> for <b>0.2 s</b> since engine speed increases <b>~200 rpm or more</b> of target idle speed.</li> <li>Selector lever position is D or R position.</li> </ul> </li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>The check engine light illuminates if the TCM detects the above malfunction condition during the first drive cycle.</li> <li>The automatic transaxle warning light does not illuminate.</li> <li>PENDING CODE is available.</li> <li>FREEZE FRAME DATA is available.</li> <li>DTC is stored in the TCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Set to emergency mode.</li> <li>Inhibits learning control.</li> <li>Inhibits manual mode.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> <li>Inhibits AAS.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>PCM DTC is stored.</li> <li>Battery malfunction</li> <li>Generator malfunction</li> <li>TCM connector or terminals malfunction</li> <li>TCM power supply circuit malfunction <ul style="list-style-type: none"> <li>Short to ground in wiring harness between AT 15 A fuse and TCM terminal A</li> <li>AT 15 A fuse malfunction</li> <li>Open circuit in wiring harness between battery positive terminal and TCM terminal A</li> </ul> </li> </ul>
<b>SYSTEM WIRING DIAGRAM</b>	<p>The diagram illustrates the power supply circuit for the TCM. It starts with the battery (4) connected to ground. The power line passes through an AT 15 A fuse and then to the TCM terminal A (6) via a connector (7). A detailed view of the TCM wiring harness-side connector shows terminals I, J, K, L, M, N, C, D, E, F, G, H, and a sub-connector with terminals A and B. An arrow indicates the location of the connector on the TCM.</p>

## Diagnostic procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA/SHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the freeze frame data/snapshot data been recorded on the repair order?</li> </ul>	Yes No	Go to the next step. Record the freeze frame data/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	<b>VERIFY PCM DTC</b> <ul style="list-style-type: none"> <li>Perform the PCM DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
4	<b>INSPECT BATTERY</b> <ul style="list-style-type: none"> <li>Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Recharge or replace the battery, then go to Step 8. (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
5	<b>INSPECT GENERATOR</b> <ul style="list-style-type: none"> <li>Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the generator, then go to Step 8. (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
6	<b>INSPECT TCM CONNECTOR AND TERMINALS</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the TCM connector.</li> <li>Visually inspect the TCM connector and terminals.</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	<b>INSPECT TCM POWER SUPPLY CIRCUIT</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Access the PID VPWR using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM PID/ DATA MONITOR INSPECTION [FW6A-EL, FW6AX-EL].)</li> <li>Is the PID value <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the AT 15 A fuse. <ul style="list-style-type: none"> <li>If the fuse is burnt out:               <ul style="list-style-type: none"> <li>Refer to the wiring diagram and verify whether or not there is a common connector between AT 15 A fuse and TCM terminal A.</li> <li><b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>Repair or replace the malfunctioning part.</li> </ul> </li> <li><b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has a short to ground.</li> <li>Replace the fuse.</li> </ul> </li> </ul> </li> <li>If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>Replace the malfunctioning fuse.</li> </ul> </li> <li>If the fuse is normal:               <ul style="list-style-type: none"> <li>Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and TCM terminal A.</li> <li><b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>Repair or replace the malfunctioning part.</li> </ul> </li> <li><b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has an open circuit.</li> </ul> </li> </ul> </li> </ul> Go to the next step.

STEP	INSPECTION	ACTION	
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FW6A-EL, FW6AX-EL].)</li> <li>• Perform the following procedure to ensure that the DTC has been resolved:               <ol style="list-style-type: none"> <li>1. Drive the vehicle for <b>5 s or more</b> under the following condition:                   <ul style="list-style-type: none"> <li>• Selector lever position: D or R position</li> </ul> </li> </ol> </li> <li>• Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FW6A-EL, FW6AX-EL].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FW6A-EL, FW6AX-EL].)
		No	DTC troubleshooting completed.