

COOLING FAN MOTOR INSPECTION [SKYACTIV-D 2.2]

id0112s6801800

Part Inspection

1. Verify that the battery is fully charged. (See BATTERY INSPECTION [SKYACTIV-D 2.2].)
2. Disconnect the cooling fan motor connector (2 terminals).
3. Install a tester and battery to the cooling fan motor connector (2 terminals) as shown in the figure.
4. Verify that each cooling fan motor operates smoothly at the standard current.
 - If there is any malfunction, replace the applicable part.

Cooling fan motor No.1, No.2 standard current
15—21 A [12 V]

