





DTC P0030:00	A/F sensor heater control circuit range/performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> A/F sensor heater control current is less than 0.573 A or exceeds 6.072 A on for a continuous 5 s with the following condition met. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 11 V or more A/F sensor heater control duty value: 20—80 % <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is an intermittent monitor (A/F sensor). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> PCM restricts engine torque. Inhibits the EGR control. Inhibits the diesel particulate filter regeneration control. Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> A/F sensor connector or terminals malfunction A/F sensor heater malfunction Short to ground or open circuit in A/F sensor heater power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between ENGINE1 15 A fuse and A/F sensor terminal C ENGINE1 15 A fuse malfunction Open circuit in wiring harness between main relay terminal C and A/F sensor terminal C Short to ground in wiring harness between A/F sensor terminal D and PCM terminal 1CG PCM connector or terminals malfunction Short to power supply in wiring harness between A/F sensor terminal D and PCM terminal 1CG Open circuit in wiring harness between A/F sensor terminal D and PCM terminal 1CG PCM malfunction

MAIN RELAY
TERMINAL CA/F SENSOR
WIRING HARNESS-SIDE
CONNECTOR

PCM WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT A/F SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the A/F sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	INSPECT A/F SENSOR HEATER <ul style="list-style-type: none"> Inspect the A/F sensor heater. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the A/F sensor, then go to Step 10. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	INSPECT A/F SENSOR HEATER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the A/F sensor connector is disconnected. Switch the ignition ON (engine off). Measure the voltage at the A/F sensor terminal C (wiring harness-side). Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE1 15 A fuse. • If the fuse is blown: — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: — Replace the fuse. • If the fuse is normal: — Repair or replace the wiring harness for a possible open circuit. Go to Step 10.
6	INSPECT A/F SENSOR HEATER CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the A/F sensor connector is disconnected. Switch the ignition off. Inspect for continuity between A/F sensor terminal D (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 10.
		No	Go to the next step.
7	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
8	INSPECT A/F SENSOR HEATER CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the A/F sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the A/F sensor terminal D (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.

STEP	INSPECTION	ACTION	
9	INSPECT A/F SENSOR HEATER CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the A/F sensor and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between A/F sensor terminal D (wiring harness-side) and PCM terminal 1CG (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
10	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the Drive Mode Type A. (See OBD DRIVE MODE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.