

**DTC U0415:00**

id060200814400

<b>DTC U0415:00</b>	<b>CAN system communication error</b>
<b>DETECTION CONDITION</b>	• Error detected in signal from DSC HU/CM via CAN communication
<b>FAIL-SAFE FUNCTION</b>	• Control enabled • Power steering malfunction indicator light: Not illuminated
<b>POSSIBLE CAUSE</b>	• DSC HU/CM malfunction
<b>SYSTEM WIRING DIAGRAM</b>	—

**Diagnostic Procedure**

Step	Inspection	Action
1	<b>INSPECT FOR DSC HU/CM MALFUNCTION</b> <ul style="list-style-type: none"><li>Using the M-MDS, perform the DTC inspection for the DSC HU/CM. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)</li><li>Are any DTCs detected?</li></ul>	Yes Go to applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) DTC troubleshooting completed, then go to the next step.
		No Go to the next step.
2	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"><li>Clear the DTC from the memory. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)</li><li>Is the same DTC present? (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)</li></ul>	Yes Replace the DSC HU/CM. (See DSC HU/CM REMOVAL/INSTALLATION.)
		No DTC troubleshooting completed.